

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate www.vevor.com/support

GRIDDLE PAN USER MANUAL

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

GRIDDLE PAN

Model: GP23



Note: the quantity of parts shown in the manual is the actual usage and the unused parts are spare parts.

NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.



Warning-To reduce the risk of injury, user must read instructions manual carefully.

IMPORTANT SAFEGUARDS

Thank you for using this product. In order to make sure that you can operate the machine correctly, read this instruction carefully before operation and keep it properly for future reference. Please be sure to read the precautions and safety rules in this page to ensure your safe use.

This manual will outline safety warnings and precautions, operating, maintenance and cleaning. The warnings and instructions reviewed in this manual cannot cover all possible conditions and situations that may occur. Caution and common sense are not built into this product, since we believe that the uses will comply with these codes.

Please read ALL the instructions before using your machine.

1. **DO NOT** let children and minors and pet get close to or touch the machine.
2. **DO NOT** touch the hot surface directly with your hands. Must use anti scald gloves.
3. Using any accessories or attachments that are not provided or recommended by the manufacturer may cause injury.
4. Do not use it with poor ventilation places or for commercial purposes.
5. Do not attempt to modify the machine in any way.
6. If the machine is not to be used for a long period of time, clean and cover it and store it in a dry and safe place.
7. **KEEP IT OUT OF CHILDREN'S REACH.**
8. Never leave it unattended while in use.
9. Avoid using it in the presence of flammable liquids, gases, dust or other explosive situations.

10. Extreme caution must be taken when moving an appliance containing hot oil or other hot liquids.
11. Children shall not play with the machine alone. Cleaning and user maintenance shall not be made by children without supervision.
12. The machine must never be left unattended during operation or cleaning.
13. Make sure that the product is always placed on a firm, level combustion support.
14. The machine should be located in an open area with good ventilation, away from trees and fences.
15. While every effort has been made in the manufacture of your machine to remove any sharp edge, you should handle all components with care in order to avoid accidental injury.
16. Keep fire extinguisher within safe and accessible distance and make sure those operating the machine are trained to use it.
17. Keep away from flammable material and fluids such as petroleum, alcohol, diesel fuel, kerosene and charcoal lighter fluid or vehicles while in use.
18. **DO NOT CLEAN IT WITH ANY ABRASIVE MATERIAL.**
19. **Do NOT** store the machine until surfaces are cold.
20. **DO NOT** wear loose clothing, and ensure that long hair is tied back when around the machine when it is hot or in use.
21. **DO NOT** use this product as a furnace.
22. Ensure the product has a minimum of 2 meters overhead clearance and has a minimum of 2 m clearance from other surrounding items.
23. This machine is intended for domestic cooking only. It is not designed for commercial or industrial purposes.
24. Never use plastic or aluminum foil dishes on the machine.
25. Perishable food, plastic items and aerosols may be affected by heat and should not be stored above or below the machine unit.
26. Do not place clothes above the machine and avoid using it as a clothes dryer.



WARNING! This product will become very hot, do not move it during operation.

WARNING! Remove all packaging materials and keep them for future use. Packaging materials are not a toy.

WARNING! Don't let children play with the packaging materials. If they swallow the packaging materials, they will suffocate!

WARNING! Keep children and pets away. Children must not operate or play near this machine.

WARNING! Failure to follow instructions could result in death, serious bodily injury and/or property loss.

ATTENTION! Burning materials can cause oxidation and discoloration of the product surface, which is normal and does not affect its use.

ATTENTION! Uneven ignition source can cause slight deformation of the product surface, which is a normal phenomenon and does not affect the use of the product.

PRODUCT COMPONENTS


Before using the appliance for the first time, peel off any promotional materials and packaging materials, and check that the cooking plates are clean and free of dust. If necessary, wipe them over with a damp cloth. Spread over with an absorbent kitchen towel and wipe off any excess oil. When your product is heated for the first time, it may emit slight smoke or odor, which is normal for many product, and will not affect the safety of your product.

1. Please dispose of all plastic bags carefully and keep them away from children.
2. Check all components provided according to the list in this manual.
3. Make sure you have all of the parts listed. Please wear safety protective equipment: gloves and goggles.

ATTENTION! Before each use, the handle must be checked for looseness and the handle and screws must be kept tight.

ATTENTION! Whilst every care is taken in the manufacture of this product, care must be taken during assembly in case sharp edges are present.

Explosion Diagram



Note: The screws are on the inside of the product, and the nuts are on the outside of the product.

Handle x 2 PCS
Screw x 4 PCS
Nut x 4 PCS

TECHNICAL DATA

Model	Size	Metal
GP23	23.11x15.55x3.9 inch (587x395*99 mm)	SUS430 Thickness2.0mm

CLEANING MAINTENANCE AND STORAGE

1. Ensure product cooling before cleaning.
2. Product can be cleaned using a dishcloth, warm water and a commercial detergent. Avoid using abrasive cleaners, and wire wool and brushes as these may scratch the surface.
3. Before storage, always make sure the product is cool and dry.
4. Store the appliance in a dry and clean area.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support