

Wood Carts FC1359-SYT



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there is any technology or software updates on our product.

01

WARNING:

Please read this manual carefully before using the product. Failure to do so may result in serious injury.

ASSEMBLY PRECAUTIONS

- 1. Assemble only according to these instructions. Improper assembly can create hazards.
- 2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
- 3. Keep assembly area clean and well-lit.
- 4. Keep bystanders out of the area during assembly.
- 5. Do not assemble when tired or when under the influence of alcohol, drugs or medication.
- 6. The product capabilities apply to properly and completely assembled products only.
- 7. Assemble on a flat, level, hard and smooth surface capable of safely supporting the wood Cart.
- 8. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts on a clear work area.

USE PRECAUTIONS

TO PREVENT SERIOUS INJURY AND DEATH FROM TIPPING:

- 1. This product is not a toy. Do not allow children to play with or approach this item.
- 2. Use as intended only. Do not sit or stand on the wood cart.
- 3. Inspect before every use. Do not use it if parts are loose or damaged.
- 4. Use only on flat, level, and hard surfaces.

SAVE THESE INSTRUCTIONS

Assembly Instruction

Part List:


| 2pcs |
|------|
| 2pcs |
| 2pcs |
| 1pcs |
| 1pcs |
| 1pcs |
| |

Hardware List:

| 4pcs |
|------|
| 4pcs |
| |

Step 1:

Attach the handle to the leg supports, fixed with 2 bolts, washers, spring washers and nuts.




Step 2:

Attach the net onto the frame in advance.



Step 3:


Attach the front support to the leg supports, fixed with 2 bolts, washers, spring washers and nuts.



02

Step 4:

Insert the axle into the leg support with 2 large washers, Push the frame to expose the 2 holes on the axle, fixed by 2 cotter pins.



Step 5: Attach the wheel to the axle with a large washer and cotter pin.





Technical Support and E-Warranty Certificate www.vevor.com/support



Technical Support and E-Warranty Certificate www.vevor.com/support

Wood Carts

We continue to be committed to provide you tools with competitive price. "Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us.

You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.