

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate www.vevor.com/support

SWEeper USER MANUAL

MODEL:S13-001A

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

SWEEPER

MODEL:S13-001A



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

 CustomerService@vevor.com

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

DANGER!

- When using equipment, some safety precautions must be observed to prevent injury and damage. Please read these operating instructions and safety instructions carefully. Keep this well so that the information is always available to you. If you should hand over the device to other persons, please hand over these operating instructions and safety instructions. We assume no liability for accidents or damage caused by non-compliance with these instructions and the safety instructions.
- Device and packaging material are not children's toys! Children are not allowed to play with plastic bags, foils and small parts! There's a risk of ingestion and asphyxiation!

ACCESSORY CONTENT

- Sweeper
- Upper push bar
- Feeding brushes (2x)
- Connection knob (2x)
- Support disc (2x)
- Screw (2x)
- Waste container
- Lower push bar
- Nut with quick release function (2x)
- Cap (2x)
- Original operating instructions

SAFETY INSTRUCTIONS

Warning

Read all safety instructions, operating instructions, illustrations and technical data provided with this device. Failure to follow the instructions can cause serious injury.

Safety information and instructions for the future.


- Attention: Before installation and commissioning, be sure to observe the instructions for use.

- Never clean the appliance with solvents.
- Do not leave the appliance unattended.
- Protect from access by children.
- Store the appliance in a dry room.
- Do not operate a defective device.
- Use the device only for the work for which it was designed.
- Use only original accessories and spare parts.
- For damage caused by improper repairs and improper handling or. We cannot assume liability for any alienation of the application areas.
- Replace defective parts immediately.
- Do not pick up glowing or harmful objects with the sweeper.The removal of gel-shaped, liquid, flammable and explosive substances is not permitted.
- After removing metal, glass or sharp objects, firm work gloves should be worn when emptying the waste container.


PRODUCT PARAMETER







| | |
|----------------------|--------------------------------|
| Model | S13-001A |
| Sweeper Width | 650mm |
| Rubbish Bin Capacity | 20L |
| Drive Type | Hand Push |
| Product Size | 1110*650*1060mm (Maximum Gear) |
| Net Weight | 9.1 kg |


DEVICE DESCRIPTION



1. Upper push bar
2. Lower push bar
3. Sweeping machine
4. Wheel
5. Waste container
6. Feeding brushes
7. Nut with quick release function
8. Cap
9. Support disc
10. Connection knob
11. Screw







- Open the package and carefully remove the device from the package.
- Remove the packaging material as well as the packaging/transport fuses (if available).
- Check that the delivery is complete.
- Check the appliance and accessories for damage in transit.
- If possible, store the packaging until the end of the warranty period.

INTENDED USE

The intended use of the sweeper is to sweep flat and dry surfaces such as driveways, patio yards, etc....

The machine may only be used as intended.

This device is not designed for commercial or industrial use.

PRODUCT ASSEMBLY

Installation of feed brushes (Figure 3-6)

- Insert the feed brush onto the sweeper.
- Then attach the feed brush with the cap.
Pay attention to the lettering on the cap. Turn the cap in the direction of arrowhead.
- Repeat the procedure on the other side.
- To disassemble the feed brushes, turn the cap in the direction, remove the cap and the feeding brush.

MOUNTING OF PUSH BARS (FIGURE 7-10)

Mount the lower and upper push bar as shown in Figure 7 to 10. The height of the push bar can be adjusted by selecting the second mounting hole.

OPERATION

By pushing the sweeper, the feed brushes and the sweeping brush are rotated via the belt drive. The rotating feed brushes sweep the dirt to the center. This is collected by the sweeping brush and transported to the waste container.

EMPTYING THE WASTE CONTAINER (FIGURE 11)

Warning! Dusts can be hazardous to health. Wear a dust mask!

Remove the waste container from the appliance as shown in Figure 11. Empty and insert the waste collector connect back into the device.

PARKING POSITION (FIGURE 8, 12, 13)

The device can be folded for space-saving storage. To do this, loosen the lower nuts with quick-release function until the pins (figure 8) pop out of the fixation and unfold the push bar (figure 12). Alternatively, the upper nuts with quick release function can be loosened afterwards.

CLEANING AND MAINTENANCE

- Keep guards and air vents as dust and dirt free as possible.
- We recommend that you clean the appliance immediately after each use.
- Clean the appliance regularly with a damp cloth and some soap.
- Do not use detergents or solvents; these could attack the plastic parts of the device. Make sure that no water can enter the inside of the appliance.

STORAGE

Store the appliance and its accessories in a dark, dry and frost-free place. The optimal storage temperature is between 5 and 30°C. Keep the power tool in its original packaging.

TROUBLE SHOOTING

| Trouble | Possible Cause | Solution |
|---|---|--|
| <p>The rotation of the guide wheel is not flexible, and the pushing is not smooth.</p> | <p>When the pushing is not smooth, lift the machine to check the chassis guide wheel for any entanglement of small branches or debris, which may cause inflexibility in rotation.</p> | <p>Remove the debris around the guide wheel.</p> |
| <p>The feeding brush is not flexible in rotation and difficult to push when pushed.</p> | <p>When it is difficult to push forward, lift the machine to check if the chassis cannot be swept up due to excessive or large debris branches, and wrap them around the feeding brush.</p> | <p>Remove large branches and debris that cannot be swept up.</p> |
| <p>When the machine is pushed, the wheels slide and do not rotate.</p> | <p>The ground is flat and smooth, or there is water on the ground, which leads to insufficient friction of the rollers and slipping when pushed.</p> | <p>The machine cannot work on surfaces that are too smooth or have water stains.</p> |

Manufacturer: Shanghai muxinmuyeyouxiangongsi
Address: Shuangchenglu 803nong11hao1602A-1609shi, baoshanqu, shanghai 200000 CN.

Imported to AUS: SIHAO PTY LTD. 1 ROKEVA STREETEAST-WOOD NSW 2122 Australia

Imported to USA: Sanven Technology Ltd. Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730



E-CrossStu GmbH
Mainzer Landstr.69, 60329 Frankfurt am Main.



YH CONSULTING LIMITED.
C/O YH Consulting Limited Office 147, Centurion House, London Road, Staines-upon-Thames, Surrey, TW18 4AX

Made In China

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support