

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support

DRO DISPLAY USER MANUAL

MODEL: 5403F

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

DRO DISPLAY

MODEL: 5403F



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support


This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

DISPLAY FUNCTIONS

1. ON/OFF: Turn the display ON or OFF by pressing this button.
2. in/mm: Switch from inch to millimeter.
3. ZERO: Set display to zero.
4. ABS: Switch between relative ZERO and normal measuring.
5. Set: Under inch measuring system, press this button to set fractional readings between $1/32''$, $1/64''$, and $1/128''$.


TECHNICAL DATA

1. Working temperature: 0 to 40°C; relative humidity: ≤80%
2. Battery: 3V CR2032.




Measuring range (mm)	Resolution (mm/inch)	Accuracy (mm/inch)	A (mm)	L (mm)
0-150	0.01/0.0005"	±0.06/±0.0025	267	291
0-200	0.01/0.0005"	±0.08/±0.0035	310	334
0-300	0.01/0.0005"	±0.10/±0.004	410	434
0-500	0.01/0.0005"	±0.15/±0.006	612	636
0-600	0.01/0.0005"	±0.15/±0.006	725	749
0-1000	0.01/0.0005"	±0.2/±0.008	1124	1148


ASSEMBLY




For router lift, mount the vertical bracket of the scale on the top of table.



For horizontal measuring, mount the horizontal bracket on the table.



For router lift, mount the vertical bracket of the scale on the top of table.



Mount the sensor on the movable carriage.



For router lift, mount the vertical bracket of the scale on the top of table.



Use the mount base, to set the display unit at suitable location.

Address: Baoshanqu Shuangchenglu 803long 11hao 1602A-1609shi
Shanghai

Imported to AUS: SIHAO PTY LTD, 1 ROKEVA STREETEASTWOOD
NSW 2122 Australia

Imported to USA: Sanven Technology Ltd, Suite 250, 9166 Anaheim
Place, Rancho Cucamonga, CA 91730

EC	REP
-----------	------------

SHUNSHUN GmbH
Römeräcker 9 Z2021, 76351
Linkenheim-Hochstetten, Germany

UK	REP
-----------	------------

Pooledas Group Ltd
Unit 5 Albert Edward House, The
Pavilions Preston, United Kingdom

Made In China

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support



Technique Assistance et certificat de garantie électronique
www.vevor.com/support

ÉCRAN DRO MANUEL D'UTILISATION

MODÈLE : 5403F

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

DRO DISPLAY

MODÈLE : 5403F



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support


This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

DISPLAY FUNCTIONS

6. ALLUMÉ ÉTEINT: Allumez ou éteignez l'écran en appuyant sur ce bouton.
7. po/mm : Passez du pouce au millimètre.
8. ZÉRO: Mettre l'affichage à zéro.
9. ABDOS: Basculez entre le zéro relatif et la mesure normale.
10. Ensemble: Sous le système de mesure en pouces, appuyez sur ce bouton pour régler lecture fractionnée s entre 1/32", 1/64" et 1/128".

TECHNICAL DATA


3. Température de fonctionnement : 0 à 40 °C ; humidité relative : $\leq 80\%$
4. Batterie : 3 V CR2032.




Plage de mesure (mm)	Résolution (mm/pouce)	Précision (mm/pouce)	UN (mm)	L (mm)
0-150	0,01/0,0005"	$\pm 0,06/\pm 0,0025$	267	291
0-200	0,01/0,0005"	$\pm 0,08/\pm 0,0035$	310	334
0-300	0,01/0,0005"	$\pm 0,10/\pm 0,004$	410	434

0-500	0,01/0,0005"	$\pm 0,15/\pm 0,006$	612	636
0-600	0,01/0,0005"	$\pm 0,15/\pm 0,006$	725	749
0-1000	0,01/0,0005"	$\pm 0,2/\pm 0,008$	1124	1148

ASSEMBLY




Pour le levage du routeur, montez le support vertical de la balance sur le dessus de la table.




Pour une mesure horizontale, montez le support horizontal sur la table.




Pour le levage du routeur, montez le support vertical de la balance sur le dessus de la table.



Montez le capteur sur le chariot mobile.



Pour le levage du routeur, montez le support vertical de la balance sur le dessus de la table.



Utilisez la base de montage pour placer l'unité d'affichage à un emplacement approprié.

Adresse : Baoshanqu Shuangchenglu 803long 11hao 1602A-1609shi
Shanghai

Importé en Australie : SIHAO PTY LTD, 1 ROKEVA STREETASTWOOD
NSW 2122 Australie

Importé aux États-Unis : Sanven Technology Ltd, Suite 250, 9166
Anaheim Place, Rancho Cucamonga, CA 91730

EC	REP	SHUNSHUN GmbH Römeräcker 9 Z2021, 76351 Linkenheim-Hochstetten, Germany
-----------	------------	---

UK	REP	Pooledas Group Ltd Unit 5 Albert Edward House, The Pavilions Preston, United Kingdom
-----------	------------	--

Fabriqué en Chine

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technique Assistance et certificat de garantie électronique

www.vevor.com/support

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technisch Support- und E-Garantie-zertifikat

www.vevor.com/support

DRO-DISPLAY BENUTZERHANDBUCH

MODELL: 5403F

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

DRO DISPLAY

MODELL: 5403F



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.


DISPLAY FUNCTIONS

11. AN AUS: Schalten Sie das Display ein oder aus, indem Sie diese Taste drücken .
12. Zoll/mm: Wechseln Sie von Zoll auf Millimeter.
13. NULL: Anzeige auf Null setzen.
14. ABS: Zwischen relativer NULL und normaler Messung umschalten.
15. Satz: Drücken Sie zum Einstellen unter dem Zoll-Messsystem diese Taste

Bruchwerte liegen zwischen 1/32", 1/64" und 1/128".

TECHNICAL DATA


5. Arbeitstemperatur: 0 bis 40 °C; relative Luftfeuchtigkeit: $\leq 80 \%$
6. Batterie: 3V CR2032.




Messbereich (mm)	Auflösung (mm/Zoll)	Genauigkeit (mm/Zoll)	A (mm)	L (mm)
0-150	0,01/0,0005"	$\pm 0,06/\pm 0,0025$	267	291
0-200	0,01/0,0005"	$\pm 0,08/\pm 0,0035$	310	334
0-300	0,01/0,0005"	$\pm 0,10/\pm 0,004$	410	434

0-500	0,01/0,0005"	$\pm 0,15/\pm 0,006$	612	636
0-600	0,01/0,0005"	$\pm 0,15/\pm 0,006$	725	749
0-1000	0,01/0,0005"	$\pm 0,2/\pm 0,008$	1124	1148

ASSEMBLY




Zum Anheben der Oberfräse montieren Sie die vertikale Halterung der Waage oben auf dem Tisch.




Für horizontale Messungen montieren Sie die horizontale Halterung am Tisch.




Zum Anheben der Oberfräse montieren Sie die vertikale Halterung der Waage oben auf dem Tisch.



Montieren Sie den Sensor am beweglichen Schlitten.



Zum Anheben der Oberfräse montieren Sie die vertikale Halterung der Waage oben auf dem Tisch.



Verwenden Sie die Montagebasis, um die Anzeigeeinheit an einem geeigneten Ort zu platzieren.

Adresse: Baoshanqu Shuangchenglu 803long 11hao 1602A-1609shi
Shanghai

Importiert nach AUS: SIHAO PTY LTD, 1 ROKEVA STREETEASTWOOD
NSW 2122 Australien

In die USA importiert: Sanven Technology Ltd, Suite 250, 9166 Anaheim
Place, Rancho Cucamonga, CA 91730

EC	REP	SHUNSHUN GmbH Römeräcker 9 Z2021, 76351 Linkenheim-Hochstetten, Germany
-----------	------------	---

UK	REP	Pooledas Group Ltd Unit 5 Albert Edward House, The Pavilions Preston, United Kingdom
-----------	------------	--

In China hergestellt

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technisch Support- und E-Garantiezertifikat

www.vevor.com/support

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Tecnico Supporto e certificato di garanzia elettronica

www.vevor.com/support

IL VISUALIZZATORE VISUALIZZA IL MANUALE UTENTE

MODELLO: 5403F

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

DRO DISPLAY

MODELLO: 5403F



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support


This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

DISPLAY FUNCTIONS

16. ACCESO SPENTO: Accendere o spegnere il display premendo questo pulsante.
17. pollici / mm: Passa dal pollice al millimetro.
18. ZERO: Imposta il display su zero.
19. ADDOMINALI: Passa dallo ZERO relativo alla misurazione normale.
20. Impostato: Nel sistema di misurazione in pollici, premere questo pulsante per impostare la lettura frazionaria è compresa tra 1/32", 1/64" e 1/128".

TECHNICAL DATA


7. Temperatura di lavoro: da 0 a 40 °C; umidità relativa: $\leq 80\%$
8. Batteria: CR2032 da 3 V.




Campo di misura (mm)	Risoluzione (mm/pollici)	Precisione (mm/pollici)	UN (mm)	I (mm)
0-150	0,01/0,0005"	$\pm 0,06/\pm 0,0025$	267	291
0-200	0,01/0,0005"	$\pm 0,08/\pm 0,0035$	310	334
0-300	0,01/0,0005"	$\pm 0,10/\pm 0,004$	410	434

0-500	0,01/0,0005"	$\pm 0,15/\pm 0,006$	612	636
0-600	0,01/0,0005"	$\pm 0,15/\pm 0,006$	725	749
0-1000	0,01/0,0005"	$\pm 0,2/\pm 0,008$	1124	1148


ASSEMBLY




Per il sollevamento della fresatrice, montare la staffa verticale della bilancia sulla parte superiore del tavolo.




Per la misurazione orizzontale, montare la staffa orizzontale sul tavolo.




Per il sollevamento della fresatrice, montare la staffa verticale della bilancia sulla parte superiore del tavolo.



Montare il sensore sul carrello mobile.



Per il sollevamento della fresatrice, montare la staffa verticale della bilancia sulla parte superiore del tavolo.



Utilizzare la base di montaggio per posizionare l'unità display in una posizione adatta.

Indirizzo: Baoshanqu Shuangchenglu 803long 11hao 1602A-1609shi
Shanghai

Importato in AUS: SIHAO PTY LTD, 1 ROKEVA STREETEASTWOOD
NSW 2122 Australia

Importato negli Stati Uniti: Sanven Technology Ltd, Suite 250, 9166
Anaheim Place, Rancho Cucamonga, CA 91730

EC	REP	SHUNSHUN GmbH Römeräcker 9 Z2021, 76351 Linkenheim-Hochstetten, Germany
-----------	------------	---

UK	REP	Pooledas Group Ltd Unit 5 Albert Edward House, The Pavilions Preston, United Kingdom
-----------	------------	--

Made in China

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Tecnico Supporto e certificato di garanzia elettronica

www.vevor.com/support

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Técnico Certificado de soporte y garantía electrónica

www.vevor.com/support

MANUAL DEL USUARIO DE LA PANTALLA DRO

MODELO: 5403F

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

DRO DISPLAY

MODELO: 5403F



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support


This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

DISPLAY FUNCTIONS

21. ENCENDIDO APAGADO: Encienda o apague la pantalla presionando este botón.
22. pulgadas/mm: Cambie de pulgadas a milímetros.
23. CERO: Ponga la pantalla a cero.
24. ABDOMINALES: Cambie entre CERO relativo y medición normal.
25. Colocar: En el sistema de medición en pulgadas, presione este botón para configurar lecturas fraccionarias entre 1/32", 1/64" y 1/128".

TECHNICAL DATA


9. Temperatura de trabajo: 0 a 40 °C; humedad relativa: $\leq 80\%$
10. Batería: 3V CR2032.




Rango de medición (mm)	Resolución (mm/pulgada)	Exactitud (mm/pulgada)	A (mm)	I (mm)
0-150	0,01/0,0005"	$\pm 0,06/\pm 0,0025$	267	291
0-200	0,01/0,0005"	$\pm 0,08/\pm 0,0035$	310	334
0-300	0,01/0,0005"	$\pm 0,10/\pm 0,004$	410	434

0-500	0,01/0,0005"	$\pm 0,15/\pm 0,006$	612	636
0-600	0,01/0,0005"	$\pm 0,15/\pm 0,006$	725	749
0-1000	0,01/0,0005"	$\pm 0,2/\pm 0,008$	1124	1148


ASSEMBLY




Para levantar el enrutador, monte el soporte vertical de la báscula en la parte superior de la mesa.



Para mediciones horizontales, monte el soporte horizontal en la mesa.




Para levantar el enrutador, monte el soporte vertical de la báscula en la parte superior de la mesa.



Monte el sensor en el carro móvil.



Para levantar el enrutador, monte el soporte vertical de la báscula en la parte superior de la mesa.



Utilice la base de montaje para colocar la unidad de visualización en la ubicación adecuada.

Dirección: Baoshanqu Shuangchenglu 803long 11hao 1602A-1609shi
Shanghai

Importado a AUS: SIHAO PTY LTD, 1 ROKEVA STREETEASTWOOD
NSW 2122 Australia

Importado a EE. UU.: Sanven Technology Ltd, Suite 250, 9166 Anaheim
Place, Rancho Cucamonga, CA 91730

EC	REP	SHUNSHUN GmbH Römeräcker 9 Z2021, 76351 Linkenheim-Hochstetten, Germany
-----------	------------	---

UK	REP	Pooledas Group Ltd Unit 5 Albert Edward House, The Pavilions Preston, United Kingdom
-----------	------------	--

Hecho en china

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Técnico Certificado de soporte y garantía electrónica

www.vevor.com/support

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Techniczny Certyfikat wsparcia i e-gwarancji

www.vevor.com/support

INSTRUKCJA OBSŁUGI WYŚWIETLACZA DRO

MODEL: 5403F

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

DRO DISPLAY

MODEL: 5403F



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support


This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

DISPLAY FUNCTIONS

26. WŁ./WYŁ.: Włączyć lub wyłączyć wyświetlacz naciskając ten przycisk.
27. cale/mm: Przełączyć z cala na milimetr.
28. ZERO: Ustawić wyświetlacz na zero.
29. ABS: Przełączanie między względnym zerem a normalnym pomiarem.
30. Ustawić: W systemie miar w calach naciśnij ten przycisk, aby ustawić odczyt ułamkowy mieści się w zakresie 1/32", 1/64" i 1/128".


TECHNICAL DATA

11. Temperatura pracy: 0 do 40 °C; wilgotność względna: ≤80%
12. Bateria: 3 V CR2032.




Zakres pomiarowy (mm)	Rezolucja (mm/cale)	Dokładność (mm/cale)	A (mm)	L (mm)
0-150	0,01/0,0005"	±0,06/±0,0025	267	291
0-200	0,01/0,0005"	±0,08/±0,0035	310	334
0-300	0,01/0,0005"	±0,10/±0,004	410	434
0-500	0,01/0,0005"	±0,15/±0,006	612	636
0-600	0,01/0,0005"	±0,15/±0,006	725	749
0-1000	0,01/0,0005"	±0,2/±0,008	1124	1148


ASSEMBLY




W przypadku podnośnika routera zamontuj pionowy wspornik skali na górze stołu.




Do pomiaru poziomego zamontuj wspornik poziomy na stole.



W przypadku podnośnika routera zamontuj pionowy wspornik skali na górze stołu.



Zamontuj czujnik na ruchomym wózku.



W przypadku podnośnika routera zamontuj pionowy wspornik skali na górze stołu.



Użyj podstawy montażowej, aby ustawić wyświetlacz w odpowiednim miejscu.

Adres: Baoshanqu Shuangchenglu 803long 11hao 1602A-1609shi
Szanghaj

Import do AUS: SIHAO PTY LTD, 1 ROKEVA STREETEASTWOOD NSW
2122 Australia

Import do USA: Sanven Technology Ltd, Suite 250, 9166 Anaheim Place,
Rancho Cucamonga, CA 91730

EC	REP	SHUNSHUN GmbH Römeräcker 9 Z2021, 76351 Linkenheim-Hochstetten, Germany
-----------	------------	---

UK	REP	Pooledas Group Ltd Unit 5 Albert Edward House, The Pavilions Preston, United Kingdom
-----------	------------	--

Wyprodukowano w Chinach

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Techniczny Certyfikat wsparcia i e-gwarancji

www.vevor.com/support

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technisch Ondersteuning en e-garantiecertificaat

www.vevor.com/support

DRO-DISPLAY GEBRUIKERSHANDLEIDING

MODEL: 5403F

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

DRO DISPLAY

MODEL: 5403F



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support


This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

DISPLAY FUNCTIONS

31. AAN UIT: Zet het display AAN of UIT door op deze knop te drukken.
32. inch/mm: Schakel van inch naar millimeter.
33. NUL: Zet het display op nul.
34. BUIKSPIEREN: Schakel tussen relatieve NUL- en normale meting.
35. Set: Druk onder het inch-meetsysteem op deze knop om in te stellen
fractionele metingen tussen 1/32", 1/64" en 1/128".


TECHNICAL DATA

13. Werktemperatuur: 0 tot 40 °C; relatieve vochtigheid: ≤80%
14. Batterij: 3V CR2032.




Meetbereik (mm)	Oplossing (mm/inch)	Nauwkeurigheid (mm/inch)	A (mm)	L (mm)
0-150	0,01/0,0005"	±0,06/±0,0025	267	291
0-200	0,01/0,0005"	±0,08/±0,0035	310	334
0-300	0,01/0,0005"	±0,10/±0,004	410	434
0-500	0,01/0,0005"	±0,15/±0,006	612	636
0-600	0,01/0,0005"	±0,15/±0,006	725	749
0-1000	0,01/0,0005"	±0,2/±0,008	1124	1148


ASSEMBLY




Voor het optillen van de router monteert u de verticale beugel van de weegschaal op de bovenkant van de tafel.



Voor horizontale metingen monteert u de horizontale beugel op de tafel.



Voor het optillen van de router monteert u de verticale beugel van de weegschaal op de bovenkant van de tafel.



Monteer de sensor op de beweegbare wagen.



Voor het optillen van de router monteert u de verticale beugel van de weegschaal op de bovenkant van de tafel.



Gebruik de montagebasis om het display op een geschikte locatie te plaatsen.

Adres: Baoshanqu Shuangchenglu 803long 11hao 1602A-1609shi
Shanghai

Geïmporteerd naar AUS: SIHAO PTY LTD, 1 ROKEVA
STREETEASTWOOD NSW 2122 Australië

Geïmporteerd naar de VS: Sanven Technology Ltd, Suite 250, 9166
Anaheim Place, Rancho Cucamonga, CA 91730

EC	REP	SHUNSHUN GmbH Römeräcker 9 Z2021, 76351 Linkenheim-Hochstetten, Germany
-----------	------------	---

UK	REP	Pooledas Group Ltd Unit 5 Albert Edward House, The Pavilions Preston, United Kingdom
-----------	------------	--

Gemaakt in China

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technisch Ondersteuning en e-garantiecertificaat

www.vevor.com/support

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Teknisk Support och e-garanticertifikat

www.vevor.com/support

DRO DISPLAY BRUKSANVISNING

MODELL: 5403F

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

DRO DISPLAY

MODELL: 5403F



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support


This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

DISPLAY FUNCTIONS

36. PÅ AV: Slå PÅ eller AV skärmen genom att trycka på denna knapp.
37. in/mm: Växla från tum till millimeter.
38. NOLL: Ställ in displayen på noll.
39. MAGMUSKLER: Växla mellan relativ NOLL och normal mätning.
40. Uppsättning: Under tummätningssystem, tryck på denna knapp för att ställa in
bråkavläsning s mellan 1/32", 1/64" och 1/128".

TECHNICAL DATA


15. Arbetstemperatur: 0 till 40 °C; relativ luftfuktighet: ≤80%
16. Batteri: 3V CR2032.




Mätområde (mm)	Upplösning (mm/tum)	Noggrannhet (mm/tum)	A (mm)	L (mm)
0-150	0,01/0,0005"	±0,06/±0,0025	267	291
0-200	0,01/0,0005"	±0,08/±0,0035	310	334
0-300	0,01/0,0005"	±0,10/±0,004	410	434
0-500	0,01/0,0005"	±0,15/±0,006	612	636
0-600	0,01/0,0005"	±0,15/±0,006	725	749

0-1000	0,01/0,0005"	$\pm 0,2/\pm 0,008$	1124	1148
--------	--------------	---------------------	------	------


ASSEMBLY




För fräsluft, montera vågens vertikala fäste på toppen av bordet.




För horisontell mätning, montera det horisontella fästet på bordet.




För fräsluft, montera vågens vertikala fäste på toppen av bordet.



Montera sensorn på den rörliga vagnen.



För fräsluft, montera vågens vertikala fäste på toppen av bordet.



Använd monteringsbasen för att ställa in displayenheten på lämplig plats.

Adress: Baoshanqu Shuangchenglu 803long 11hao 1602A-1609shi
Shanghai

Importerad till AUS: SIHAO PTY LTD, 1 ROKEVA STREETEASTWOOD
NSW 2122 Australien

Importerad till USA: Sanven Technology Ltd, Suite 250, 9166 Anaheim
Place, Rancho Cucamonga, CA 91730

EC	REP	SHUNSHUN GmbH Römeräcker 9 Z2021, 76351 Linkenheim-Hochstetten, Germany
-----------	------------	---

UK	REP	Pooledas Group Ltd Unit 5 Albert Edward House, The Pavilions Preston, United Kingdom
-----------	------------	--

Tillverkad i Kina

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Teknisk Support och e-garanticertifikat

www.vevor.com/support