

Technical Support and E-Warranty Certificate www.vevor.com/support

## HAIR STRAIGHTENER

**MODEL: WF045C** 

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and doses not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.



# HAIR STRAIGHTENER

MODEL: WF045C



#### **NEED HELP? CONTACT US!**

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

#### HAIR STRAIGHTENER USER MANUAL

Please read the instructions carefully before use and retain this manual in a safe place for future reference, and pass the manual onto any subsequent users.

About Ion Technology: The built-in ionic generator emits negative ions, negatively charged atoms and molecules that can interact with the molecular particles in your hair. They seal the hair cuticle and reduce frizziness, split ends and knotting, while increasing hair manageability, leaving hair silky and lustrous!

#### **SAFETY WARNINGS:**

- Read all of the instructions carefully before use.
- -This appliance can be used by juniors aged from 15 years and above and persons lack of experience and knowledge if they have been given supervision or instruction concerning the safety use of the appliance and understand the hazards involved Children shall not play with the appliance, Cleaning and user maintenance shall not be made by children unless they are older than 15 years and supervised
- -Keep away from water.
- Unplug the device immediately after use in order to reduce the risk of death in case of an electrica shock.
- -Do not put the appliance in a place where it can slide into a sink or a bathtub and do not keep the device in such a place.
- -Do not use the appliance while you are taking a shower.
- -Do not immerse or drop it into water or other liquids. If an appliance falls into water, unplug immediately at the power outlet
- -Never leave the hair straightener unattended in order to reduce the risk of burn, electrical shock, fire or damage.
- -Close observation is required when the appliance is in use to prevent usage by a child or other persons whom it is not intended for. Do not let children to play with this hair straightener appliance.

- -If the cable or plug of the hair straightener is damaged or not working properly or dropped into water, stop using it.
- -If the cable or plug of this appliance is damaged, it must be changed by the manufacturer or similarly qualified persons in order to avoid a hazard.
- -In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- -Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- -Keep the electricity cable away from hot surfaces.
- -Never operate this appliance if it has a damaged cord or plug If it is not working properly or if it has been dropped or damaged, or dropped into water, return the appliance to a service center for examination and repair.
- -Do not place the heated unit directly on any surface while it is hot or plugged in.
- -Do not use on people while they are sleeping.
- Do not use on pets.
- -Do not use in open areas, or places where sprays are used or oxygen is given.
- -The hair straightener's heater can get extremely hot during use, Do not touch the hot area with exposed skin.
- -Only use this appliance on dry, natural hair without any flammable hair products.
- -This appliance is not suitable for artificial hair.
- -This appliance is not intended for commercial or salon use

#### **POWER CORD SAFETY TIPS:**

- -Never pull or yank the cord of the appliance and do not use an extension cord with this appliance.
- -Insert plug grasp it firmly and guide it into outlet.
- -To disconnect the appliance, grasp plug and remove it from outlet.

- -Before each use inspect the power cord for cuts and/or abrasion marks.if any are found this indicates that the appliance should be serviced and the line cord replaced.
- -Never wrap the cord tightly around the appliance as this could place undue stress on the cord where it enters the appliance and cause it to fray and break.
- -DO NOT OPERATE THE APPLIANCE IF THE POWER CORD SHOWS ANY DAMAGE OR IF THE APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKINGENTIRELY.

# APPEARANCE AND INFORMATION: Anion hair straightener

#### **LED Display**

Temperature adjustment/MCH heater ON/OFF button

360-degree rotatable power cord

Built-in heater



### Parameters WF045C (anion):

Product model	WF045C	imensions	355*123*65mm	
ated voltage	100-240V AC	Operating	100 <b>℃</b> -230 °C or	
		temperature	210°F -450°F	
Rated	50-60 Hz	Operating	LED digital	
frequency	30-60 HZ	indication		
Rated power	55W	Heating unit	MCH	

#### **OPERATION INSTRUCTIONS:**

#### PLEASE USE IT ON DRY HAIR ONLY

**Step 1:** Insert power plug into a wall socket. Press the power button the LED light will on and the heater begins to warm up. Press +/- button to adjusting temperature according to your hair types.

**Step 2:** Press +/- button to choose different temperature settings according to different hair types. Different temperature settings available are

**WF045C**: 210 F -450 F(100°C-230°C). **WF066I**: 270 F -450 F(140°C-230°C).

**Step 3:** When the brush is heating up, the temperature setting LED light will keep flashing until the set temperature is reached, Once the temperature setting LED light stays on, the brush is ready to use for hair straightening Please hold the brush handle and keep a safe distance from exposed skin and eyes.

**Step 4:** For straightening curly hair or other hard to straighten hair, set the temperature to 230°C (450°F) For tinted & permed hair or fine blond hair, set the temperature to 150°C~180\*C (310°F~350\*F). For other ordinary hair, set the temperature to 180°C-200°C(350°F~390°F)

**Step 5:** Hold certain parts of your hair with clips (thickness less than 100mm) from top, middle, back, front and sides in order to make hair the styling operation easier.

**Step 6:** First straighten the lower layers of your hair and then pass to upper layers.

Take a small part of your hair.disperse it in the middle of the brush and then pull tight. Hold the hair straightener in one of your hands and comb your hair starting from the root to the tips in 15 seconds without stopping. Do not hold the hair straightener in one place for more than 10 seconds. Make sure that you are holding the hair straightener by its handle. Repeat this operation until your hair is straightened as desired.

**Step 7:** Once the hair straightening is complete,long press the power button to power off the hair straightener. Then unplug it and let it cool down before storing. **Note:** Please do not comb your hair before it has cooled down, otherwise the hairstyle may be affected.

#### **AUTO-OFF SAFETY FUNCTION:**

The hair straightener has an auto-off safety feature and will turn off after 60 minutes of use. If you want to use it again, simply press the power button to turn it on again.

#### **TEMPERATURE SETTING:**

The default operating temperature setting is 410° F(210° C)You can short press the temperature adjustment button to adjust the operating temperature. During heating, the LED temperature display will flash. It will stop flashing and stay on when the set temperature is reached.

#### **OPERATING TEMPERATURE ADVICE**

Setting 1;  $150^{\circ}$  C(310° F), suitable for first time users or users with thin, fine hair or bleached hair. Setting 2;  $180\text{C}(350^{\circ}$  F), suitable for dyed or dark color hair. Settings  $3 \& 4;200^{\circ}$  C(390° F)to  $210^{\circ}$  C(410° F), suitable for normal or slightly curled hair. Setting 5;  $230^{\circ}$  C(450° F), suitable for thick and very curly hair, or difficult to style hair.

#### **ATTENTION:**

Your hair straightener has an automatic turning off feature for your security, the hair straightener turns off after a usage of 60 minutes. If you want to use it again, you can press the power button to turn on the appliance.

First time usage of this appliance may occasionally cause a slight burning smell or very light smoke, which is caused by the small amount of residual oil on the MCH heater burning off when heated. This is normal and safe to use and should only last a few seconds.

"It is important to set the appropriate working temperature for your hair before usage in order to prevent your hair getting damaged.

When the MCH heater is on, the appliance can get extremely, hot make sure you keep it away from eyes nose hands neck and facial areas.

#### **MAINTENANCE AND CLEANING:**

Unplug the appliance and allow it to cool.

Wipe the surfaces with a damp cloth to clean.

Do not use harsh or abrasive cleaning agents or solvents.

Store the appliance in cool, dry place.

#### **SERVICE AND GUARANTEE:**

Defects affecting product functionality appearing within the guarantee period will be corrected by eplacement or repair at our option provided

Defects from repair by an unauthorized dealer are not covered.

Consumables are excluded your statutory rights are not affected.

Warranty date: 365 days

## **ENVIRONMENTAL PROTECTION:**





To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol must not be disposed of with unsorted municipal waste, but recovered, reused or recycled



#### **FCC Information:**

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment!

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This product may cause harmful interference.
- 2)This product must accept any interference received, including interference that may cause undesired operation.

**WARNING:** Changes or modifications to this product not expressly approved by the party.responsible for compliance could void the user's authority to operate the product.

**Note:** This product has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This product generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the product off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- · Reorient or relocate the receiving antenna.
- · Increase the distance between the product and receiver.
- · Connect the product to an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for assistance.

#### CORRECT DISPOSAL



This product is subject to the provision of european Directive 2012/19/EU. The symbol showing a wheelie bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked

as such may not be discarded with normal domestic waste, but must be taken to acollection point for recycling electrical and electronic devices.

#### SHENZHEN WINFUTURE TECHNOLOGY CO., LTD.

**Address:** 6F, Huahao High-tech IndustrialPark No. 59, Gangzai Street, Xinqiao, Shajing Street Baoan District, 518125 Shenzhen Guangdong P.R. China.

Manufacturer: Shanghaimuxinmuyeyouxiangongsi

Address: Baoshanqu Shuangchenglu 803long 11hao 1602A-1609shi Shanghai

Imported to AUS: SIHAO PTY LTD.1 ROKEVA STREETEASTWOOD

NSW 2122 Australia



Pooledas Group Ltd Unit 5 Albert Edward House, The Pavilions Preston, United Kingdom pooledas123@gmail.com 01772418127



SHUNSHUN GmbH Römeräcker 9 Z2021,76351 Linkenheim-Hochstetten, Germany euvertreter@gmail.com +49 1727041930

Made In China



**Technical Support and E-Warranty Certificate** www.vevor.com/support