

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate www.vevor.com/support

YURT TENT USER MANUAL

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

YURT TENT

Model: ZJTM1184




NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

SPECIFICATIONS

Model	ZJTM1184	
Product Size	Diameter: 5m Height: 2.8m Height of Door: 1.3m Height of fence: 1.4m	
Color	Beige	

! CAUTIONS

1. Please refer to parts list to check items you received carefully, do not discard any of the packaging until you have checked that you have all the parts & hardware! Don't hesitate to contact us if you missed parts, have broken parts or have any other installation problems.
2. Select a level site clear of rocks, branches, and other hard or sharp objects to install your tent and be sure that no underground utilities are present. Do not set up your tent under trees or tall buildings to avoid potential safety hazards caused by falling objects.
3. The tent is manufactured for use as a temporary structure and does not meet structural code, the installer is responsible for anticipating weather severity for the proper time of installation.
4. As the tent needs to be fixed at any time during the building process, enlist at least one person to assist you when it is time to assemble the tent.
5. The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions. We will not be responsible for any damage caused by human factors. If there is any problem during the use of the product, please contact us in time.

! WARNING

1. Keep away from children, the elderly and other people to prevent personal injury caused by falling metal frames during installation.
2. Keep all flame and heat sources away from this tent fabric to avoid the tent burning by accidental contact.

! CARE INSTRUCTION

1. Clean debris and Keep the canvas dry when storing the tent, store the metal frame and canvas separately in the carry bag to prevent mildew or damage.
2. Use normal detergent and water for cleaning if the tent is dirty.








! PRECAUTIONS

The following precautions should be taken when you go outdoors:

1. Be certain that your tent is properly ventilated (especially if you decide to ignore the first warning and use a heater in your tent). Carbon monoxide is real, and can cause serious damage such as death. Vents and screens are built into the tent body.
2. Be sure to anchor your tent properly—this is not a free-standing tent—follow these instructions for proper staking practices and ensure that all guy lines & pegs are securely fixed.
3. Be certain that children are supervised in and around the tent at all times.
4. Do not use candles, matches or open flames of any kind in or near a tent.
5. It is better to not cook inside a tent, but if you are, do not leave cooking unattended. Make sure grills, cooking appliances and similar must not be placed nearer than 1 meter to tent canvas. There should be no use of open fires or glowing charcoal inside tents or near tent canvas - fire can spread very quickly. There should be no use of open fires or glowing charcoal inside tents or near tent canvas as there is a significant risk from the buildup of Carbon Monoxide (CO), particularly in a confined space inside the tent. All flexible tubes and couplings to the gas burner should be checked for leakage and that it is in good order.
6. Build campfires downwind and several meters away from a tent and be sure to fully extinguish campfires before leaving a campsite or before retiring for the night.
7. Exercise extreme caution when using fuel-powered lanterns or heaters inside a tent and use battery-operated lanterns whenever possible. Do not refuel lamps, heaters or stoves inside a tent. Extinguish or turn off all lanterns before going to sleep.
8. Do not smoke in a tent or store flammable liquids inside a tent. Installation of log burners or heating equipment at your own risk.
- 9.

SAVE THESE INSTRUCTIONS

PARTS LIST

NO.	NAME	DRAWING	QTY
1	Circus tent	 A line drawing of a circus tent, showing a central pole and several side poles connected by a fabric canopy.	1
2	Center pole	 A drawing of a center pole, consisting of three parallel horizontal lines.	1
3	Side pole	 A drawing of a side pole, consisting of two parallel lines that meet at a point at one end, forming a V-shape.	8
4	Large stake	 A drawing of a large stake, which is a long, thin metal rod with a pointed end and a curved, hook-like end.	8
5	Small stake	 A drawing of a small stake, which is a shorter metal rod with a pointed end and a curved, hook-like end.	8
6	Hammer	 A drawing of a hammer, showing a wooden handle and a metal head with a flat face and a curved claw.	1
7	Stake bag	 A drawing of a stake bag, which is a rectangular bag with a handle and two vertical straps.	1


ASSEMBLY INSTRUCTION

STEP 1


Fix the tent body

- Lay your tent onto the ground, keep the floor taut with partner. Stake down 8 tent corners with the small stake.

Small stake





Hammer



! NOTE:

Please don't stake down too much at this step for later adjustment.




The stake maintain an angle of 45° - 60° with the ground, so the angle of bearing capacity is the largest.


STEP 2

Prop up the tent

- Assemble the center pole through the built-in metal buckle.




- One person put centre pole on the middle point of floor for propping up the tent.



STEP 3

Install door pole

- Assemble the side poles and support the side wall with them. Fasten the plastic buckle to the side poles for better fixation.



STEP 4



Finish the tent assembly

- Fix the one-piece webbing wind rope with large stakes and tighten the adjustable buckle.
- Recommend pulling out guy ropes along the direction of every seam on the tent roof to get the perfect visual effect and stability. (Make adjustments to the tent stakes after this step, if needed.)

Large stake



Hammer



Manufacturer: Shanghaimuxinmuyeyouxiangongsi
Address: Shuangchenglu 803nong11hao1602A-1609shi, baoshanqu, shanghai
200000 CN.
EC REP: E-CrossStu GmbH.
Mainzer Landstr.69, 60329 Frankfurt am Main.
UK REP: YH CONSULTING LIMITED.
C/O YH Consulting Limited Office 147, Centurion House, London Road, Staines-
upon-Thames, Surrey, TW18 4AX
Imported to AUS: SIHAO PTY LTD.
1 ROKEVA STREETEASTWOOD NSW 2122 Australia
Imported to USA: Sanven Technology Ltd.
Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support