

Technical Support and E-Warranty Certificate www.vevor.com/support

WALL MOUNTED LADDER MODEL: M6

We continue to be committed to provide you tools with competitive price. "Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.



WALL MOUNTED LADDER

MODEL: M6



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

IMPORTANT SAFEGUARDS



WARNING:

Carefully read instructions and procedures for safe operations. and **SAVE THESE INSTRUCTIONS**

- Do not modify the ladder / platform design.
- Do not move a ladder / platform while standing on it.

• Do not use in bad weather, such as wind, rain, snow and so on, It is recommended to use the ladder in clear weather.

Before Use

• Ensure that you are fit enough to use a ladder. Certain medical conditions or medication, alcohol or drug abuse could make ladder use unsafe. The weight capacity is 420 lbs;

- When transporting ladders on roof bars or in a truck, ensure they are suitably placed to prevent damage;
- Inspect the ladder after delivery and before first use to confirm condition and operation of all parts;
- Visually check the ladder is not damaged and is safe to use at the start of each working day when the ladder is to be used;
- · For professional users regular periodic inspection is required;
- Ensure the ladder is suitable for the task;
- Do not use a damaged ladder, Before using the ladder, ensure that the ladder is securely installed to prevent personal injury and accidents;

• Remove any contamination from the ladder, such as wet paint, mud, oil or snow;

- Before using a ladder at work a risk assessment should be carried out respecting the legislation in the country of use;
- When using the ladder, do not overload the ladder to avoid personal injury or accident;
- Do not use the ladder for two or more people at the same time;
- · Minors should only use ladders under the guidance of their guardians;
- · When using a ladder, climb up or down slowly to avoid personal injury or

accident caused by falling or bumping the ladder;

- Before using a ladder after placing it for a long time, check whether the ladder is loose to prevent personal injury or accidents;
- Before installing the ladder, ensure that the mounting plate is solid and ready for use;
- To avoid personal injury, do not install a ladder if the mounting plate is rotten;
- When the installation support increases the height, adjust the site, and put the stairs to use when the ground is flat.

Positioning and Erecting the Ladder

- Ladder shall be erected at the correct position, such as the correct angle for a leaning ladder;
- Ladder shall be on an even, level and unmoveable base;
- Leaning ladder should lean against a flat nonfragile surface and should be secured before use, e.g. tied or use of a suitable stability device;
- Ladder shall never be repositioned from above;
- When positioning the ladder take into account risk of collision with the ladder
- e.g. from pedestrians, vehicles or doors. Secure doors (not fire exits) and windows where possible in the work area;
- Identify any electrical risks in the work area, such as overhead lines or other exposed electrical equipment;
- · Ladder shall be stood on its feet, not the rungs or steps;
- Ladders shall not be positioned on slippery surfaces (such as ice, shiny surfaces or significantly contaminated solid surfaces) unless additional effective measures are taken to prevent the ladder slipping or ensuring contaminated surfaces are sufficiently clean.

Using the Ladder

- Do not exceed the maximum total load for the type of ladder;
- Do not overreach; user should keep their belt buckle (navel) inside the stiles and both feet on the same step/rung throughout the task;
- Do not step off a leaning ladder at a higher level without additional security, such as tying off or use of a suitable stability device;

- Do not stand on the top three steps/rungs of a leaning ladder;
- Do not stand on the top two steps/rungs of a standing ladder without a platform and hand/knee rail;

• Do not stand on the top four steps/rungs of a standing ladder with an extending ladder at the top;

- Ladders should only be used for light work of short duration;
- · Use non-conductive ladders for unavoidable live electrical work;
- · Take precautions against children playing on the ladder;
- · Secure doors (not fire exits) and windows where possible in the work area;
- · Face the ladder when ascending and descending;
- Keep a secure grip on the ladder when ascending and descending;

Number	Name	Quantity	Picture
1	stairway	1	
2	Ring pull	1	

PRODUCT SCHEDULE

3	pull rod	1	h.
4	Screw kit (8*60expansion tube*8 pcs, M6*60 screw*8 pcs	1	

TECHNICAL PARAMETERS

Model	M6
Suitable installation height(m)	3-3.2
Install the hole opening dimensions (mm)	600*1000
Maximum load (lbs)	350
Product size (mm)	1000*600*200
Net weight(kg)	18

INSTALLATION

1. Fixed frame expansion wire fixed: the frame has the corresponding hole position, fixed with 6 screws(**Figure 2 arrow**), can be used.








Figure 2



Technical Support and E-Warranty Certificate www.vevor.com/support