

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate www.vevor.com/support

Bluetooth Door Lock HMI-2005

We continue to be committed to provide you tools with competitive price. "Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

MODEL:HMI-2005



NEED HELP? CONTACT US!


Have product questions? Need technical support? Please feel free to contact us:
Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.


WHAT'S INCLUDED

Latch and strike	Exterior Assembly	Interior Assembly	Screws
			Step 2 Step 3.1 Step 3.2 Step 4 Step 6
	What you'll need Phillips head Screwdriver Note: No drill needed		


PRODUCT OVERVIEW




EXPLOSIVE VIEW




1 Adjust the backset of latch (if needed)




2 Install latch




3 Adjust lock handle direction




3 Adjust lock handle direction




4 Install front panel




5 Connect wire connector




6 Install back panel




7 Install batteries and battery cover



8 Insert the key and test the installation



Install our lock on top (only if needed)



FCC Notices

FCC ID:2A4W4-HMI-2005

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Made in China

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate
www.vevor.com/support

APP MANUAL



Scan to Download The APP

Please read the manual carefully before installation and keep this manual at a secure place. Please refer to sales agents and professionals for information not included in this manual.

Introduction

TT Lock App is a management software for smart lock. The App and the lock communicate via Bluetooth BLE to unlock, lock, hardware upgrade, read operation record, etc. on the App. The Bluetooth key can also help open the door lock through the AI watch.

Currently, the App supports Chinese, Traditional Chinese, English, Spanish, Portuguese, Russian, French, And Malay.




Contents

- 1.Registration and login
 - 1.1 Security question settings
 - 1.2 Login authentication
 - 1.3 Verification mode
 - 1.4 Login successful
- 2.Lock management
 - 2.1 Lock adding
 - 2.2 Lock upgrade
 - 2.3 Error diagnosis and time calibration
 - 2.4 Authorized administrator
- 3.Ekey management
 - 3.1 Ekey management
 - 3.2 Deadline warning
 - 3.3 Search lock record
- 4. Type of passcode
 - 4.1 Permanent passcode
 - 4.2 Time-limited passcode
 - 4.3 One-time passcode
 - 4.4 Clear code
- 4.5 Cyclic passcode
- 4.6 Custom passcode
- 4.7 Passcode sharing
- 4.8 Passcode management
- 5.Card management
- 6.Fingerprint management
- 7.Unlock via Bluetooth
- 8.Passage Mode
- 9.System settings
 - 9.1 Key groups management
 - 9.2 Transfer admin rights
 - 9.3 Lock recycling station
 - 9.4 About the APP
- 10.Gateway management
 - 10.1 Add the gateway
 - 10.2 Manual


1. Registration and login

TT lock users can register the account by mobile phone and Email which currently support 200 countries and regions on the world. The verification code will be sent to user's mobile phone or email, and the registration will be successful after the verification.




1.1 Security question settings

You will be taken to the security question settings page when registration is successful. When log in on a new device, the user can authenticate himself by answering the above questions.




1.2 Login authentication

Log in with your mobile phone number or email account on the login page. The mobile phone number is automatically recognized by the system and does not input the country code. If you have forgotten your password, you can go to the password page to reset your password. When reset the password, you can receive a verification code from your mobile phone and email address.




When the account is logged in on the new mobile phone, it needs to be verified. When it is passed, you can log in on the new mobile phone. All the data can be viewed and used on the new mobile phone.




1.3 Verification Mode

There are two ways of security verification. One is the way to get the verification code via the account number, and the other is the way to answer the question. If the current account is set the "answer the question" verification, then when the new device is logged in, there will be an "answer question verification" option.



1.4 Login Successful

The first time you use the lock lock app, if there is no lock or key data in the account, the home page will display the button to add the lock. If there is already a lock or key in the account, the lock information will be displayed.




2. Lock Management

The lock must be added on the app before it can be used. The addition of a lock refers to the initialization of the lock by communicating with the lock via Bluetooth. Please stand beside the lock. Once the lock is added successful, you can manage the lock with the app including sending a key, sending a password, and so on.



2.1 Lock Adding


The App supports multiple types of lock, including door locks, padlocks, safe locks, smart lock cylinders, parking locks, and bicycle locks. When adding a device, you must firstly select the lock type. The lock needs to be added to the app after entering the setting mode. A lock that has not been added will enter the setting mode as long as the lock keyboard is touched. The lock that has been added needs to be deleted on the App first.



The initialization data of the lock needs to be uploaded to the network. The data needs to be uploaded when the network is available to complete the entire whole adding process.


2.2 Lock Upgrade

User can upgrade the lock firmware on the TT lock APP. The upgrade needs to be done via Bluetooth next to the lock. When the upgrade is successful, the original key, password, IC card, and fingerprint can continue to be used.




2.3 Error diagnosis and time calibration

Error diagnosis aims to help analyse the system problems. It needs to be done via Bluetooth beside the lock. If there is a gateway, the clock will be calibrated firstly through the gateway. If there is no gateway, it needs to be calibrated by the mobile phone Bluetooth.




2.4 Authorized administrator

Only the administrator can authorize the key. When the authorization is successful, the authorized key is consistent with the administrator's interface. He can send keys to others, send passwords, and more. However, the authorized administrator can no longer authorize others.



3. Ekey management

After the administrator successfully adds the lock, he owns the highest administrative rights to the lock. He can send keys to others. Meanwhile he can increase the key management that is about to expire.




Click the type of lock it will show the time-limited ekey, one-time ekey and permanent ekey.

Time-limited ekey: The ekey is valid for the specified time.


Permanent ekey: The ekey can be used permanently.

One-time ekey: The ekey will be automatically deleted once it has been used.




3.1 Ekey Management

The manager can delete ekey, reset ekey, send and adjust the ekey, meanwhile he can search the lock record.




3.2 Deadline warning

System will show two colors for deadline warning. The yellow means close to expiring and the red means it has expired.



3.3 Search lock record

The administrator can query the unlock records of each key.




4. Type of passcode

After inputting the passcode on the keyboard of the lock, press the unlock button to unlock. Passcodes are classified into permanent, time-limited, one-time, empty, loop, custom, etc.


4.1 Permanent passcode

The permanent passcode must be used within 24 hours after it is generated, otherwise it will automatically expire.




4.2 Time-limited Passcode

The time-limited passcode can own an expiration date, which is a minimum of one hour and a maximum of three years. If the validity period is within one year, the time can be accurate to the hour; if the validity period is more than one year, the accuracy is month. When the time-limited passcode is valid, it should be used within 24 hours, otherwise it will automatically expire.




4.3 One-time passcode

One-time passcode can only be used for one time, and which is available for 6 hours.




4.4 Clear code

Clear code is used to delete all the passcodes the lock has set, and which is available for 24 hours.




4.5 Cyclic passcode

The cyclic password can be reused within a specified time period, including daily type, weekday type, weekend type, and more.




4.6 Custom passcode

User can set any passcodes and validity period he wants.




4.7 Passcode sharing

The system add new communication ways of Facebook Messenger and Whatsapp to help users share the passcode.




4.8 Passcode management

All generated passcodes can be viewed and managed in the password management module. This includes the right of changing the password, deleting the password, resetting the password, and unlocking the password.




5. Card management

You need to add the IC card first. The whole process needs to be done via the app beside the lock. The validity period of the IC card can be set, either permanent or time-limited.




All IC cards can be queried and managed through the IC card management module. The remote card issuance function is displayed in the case of a gateway. If there is no gateway, the item is hidden.



6. Fingerprint management

Fingerprint management is similar to IC card management. After adding a fingerprint, you can use the fingerprint to unlock the door.





7. Unlock via Bluetooth

User can lock the door via Bluetooth and can also send the Bluetooth key to anyone.

Use APP to unlock


Click the round button at the top of the page to unlock the door. Since the Bluetooth signal has a certain coverage, please use the APP within the certain area.



8. Passage Mode


In the main interface of the app, select Passage Mode in the settings, and the date of the Passage Mode can be set, and the start time and end time of the Passage Mode can also be set.

After the Passage Mode is activated, everyone can unlock the door without needing any access permission. Passage Mode can be turned off by tapping on it again.



9. System settings


In the system settings, it includes touch unlock switch, group management, gateway management, security settings, reminder, transfer smart lock and so on.



TTLock Touch unlock setting determines whether you can open the door by touching the lock.


9.1 Key groups management

In the case of a large number of keys, you can use group management module.



9.2 Transfer admin rights


The administrator can transfer the lock to other users or to the apartment (Room Master user). Only the account that manages the lock has the right to transfer the lock.



After you enter your account, you will be transferred successfully. The account of the apartment transfer receive must be the administrator account.


9.3 Lock recycling station

If the lock is damaged and cannot be deleted, the lock can be deleted by moving it into the recycling station.



9.4 About the APP

In this module you can check the app version number.



10. Gateway management


The TTlock is directly connected via Bluetooth, that is why it is not attached by the network. The gateway is a bridge between smart locks and home WIFI networks. Through the gateway, the user can remotely view and calibrate the lock clock, read the unlock record. Meanwhile, it can remotely delete and modify the password.



10.1 Add the gateway

Please add the gateway via APP:

- Connect your phone to the WIFI network which the gateway is connected to. (wifi 2.4G)
- Activate the APP, click the button "☰" in the upper left corner--Select [Gateway]-- click the "+" --Select [G2].
- When the gateway is powered on, light flashes alternately in red and blue. Stand-by mode, ready for pairing
- Add Gateway, Select the network and fill in the password. Add complete



10.2 Manual

After a short period of time, you can see which locks are in their coverage in the app. Once the lock is bound to the gateway, the lock can be managed through the gateway.

