

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate www.vevor.com/support

PYROGRAPH MACHINE

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

PYROGRAPH MACHINE

MODEL:LH50








NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

	<p>Warning-To reduce the risk of injury, user must read instructions manual carefully.</p>
	<p>FCC STATEMENT This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)This device may not cause harmful interference, and (2)this device must accept any interference received, including interference that may cause undesired operation.</p>
	<p>CORRECT DISPOSAL This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheelie bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices</p>
	<p>This symbol, placed before a safety comment, indicates a kind of precaution, warning, or danger. Ignoring this warning may lead to an accident. Please always follow the recommendation below to reduce the risk of injury, fire, or electrocution.</p>
	<p>This product is of protection class II. That means it is equipped with enhanced or double insulation.</p>

IMPORTANT SAFEGUARDS

WARNING:

1. Warnings must be followed carefully to avoid body injury. Improper use may result in electric shock, fire, personal injury, and other damage:

- 1) Keep unplugged when moving the machine.
- 2) Keep unplugged when installing accessories.
- 3) Place on a flat and stable platform and operate under ventilated conditions.
- 4) Wear special protective equipment when operating the machine.
- 5) Do not use this machine in a hazardous location.
- 6) Only use it when the machine is working correctly.
- 7) Do not disassemble and repair this machine.
- 8) Do not use an unsuitable AC outlet.
- 9) Do not touch the heating plate when the machine is heating.
- 10) Do not use in humid environments or in contact with water. Also, do not infiltrate liquid in the machine to prevent fire or electric shock caused by a short circuit.
- 11) Do not use the power supply that does not meet the rated voltage. The power supply that does not meet the specified voltage may cause fire or electric shock.
- 12) Ensure that the machine is grounded so as not to cause harm to body.
- 13) Do not touch the rotating rod or bearing part with your fingers during use in case of injuries.
- 14) If the machine is not in use for a long time, please unplug the power cord from the socket.
- 15) Do not use the machine during thunderstorms or lightning to avoid damage to the machine.
- 16) Place the machine smoothly on the flame-retardant table and keep away from flammable and explosive items.
- 17) Please stop using it if the machine smokes, emits a peculiar smell, or becomes noisy and in other abnormal conditions.
- 18) This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with

the appliance. Cleaning and user maintenance shall not be made by children without supervision.


2. Type Y attachment: If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

3. In order to avoid a hazard due to inadvertent resetting of the thermal cutout, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

4. In the process of temperature adjustment, there will be a slight delay in the digital display temperature, which is a normal phenomenon, please wait a moment.

SAVE THESE INSTRUCTIONS

Instruction Manual of LPyrograph Machine



1) Pyrograph machine switch: Turn on the switch when using it, and turn it off when not in use to avoid danger.

2) Thermostat: It is used to adjust the temperature of the pyrograph pen. The light gray part is the normal adjustment of the rendering temperature, and the red part is the high temperature area. The temperature adjustment of the electrical heating

wire pen is to slowly adjust the temperature through the temperature regulator. If it is temperature display, adjust the temperature to 700 degrees and then slowly lower it, it would be best the temperature is around 350-600 degrees and the low temperature rendering is about 350-450 degrees. When adjusting the temperature, adjust the tip of the electrical heating wire pen from a little grayish orange to not red. Don't be too red, too high temperature will make the pen soft and unable to draw normally, the performance will drop sharply, and the line drawn will be burnt.

3) pyrograph pen socket: The pyrograph pen plug should be closely matched with the socket, the plug should be inserted into the bottom of the socket, which should be closely matched to avoid overheating and burning accessories


Thermometer : The temperature of the pyrography machine is adjusted by adjusting the Temperature value, and the temperature adjustment display range is 300-700 degrees.

Precautions for pyrograph machine:

- 1) Tighten the screw of the pen tip when applying the pen tip, avoid poor contact between the pen tip and the terminal so that the pen tip is not hot. The overheating of the terminal will burn out the accessories, If the terminal is too hot, that is the pen tip is not tightly fastened, and it should be fastened with a screwdriver in time.
- 2) Select a heating wire under 1 mm as the pen tip. Do not choose other non-heating wire materials such as iron wire as the pen tip, which is very dangerous and easy to burn out all the accessories in the movement, and it is easy to cause electric shock and fire.


Correct installation of pen point of pyrograph

The pen point of pyrograph is not hot, and the temperature is suddenly high, and suddenly low. There are sparks coming from the pen point and the penholder is hot to grasp. What are the reasons? It's because the incorrect installation of the pen point.




① Here the top screw needs to exit more than 4 mm, and the screw needs to exit this distance and inserts into the pen point.

② It' s wrong for screw to insert into the pen point at this distance.




① The feet of the pen point shall be inserted into the copper binding post for more than 8 mm.

② The pen point copper binding post



① Tighten the screw with the screwdriver and tighten the feet of the pen point! It must be tightly closed; otherwise, the pen point won't be heated or its heating is abnormal or even sparks.

② The screw leaks outside too much, and it's sure the feet of pen point is not tightened which is wrong.



It' s the essential to install the pen point correctly.

there are some symptoms of the incorrect installation of pen point , which are the abnormal heat of pen point , unstable temperature of pen point, sparks generating from the pen point, the heating of copper column and the burning hot of pen holder.

Technical data


Model	LH50	
Rated voltage	120V~ 60Hz For US	220-240V~ 50Hz For EU or AU
Power	20W	

Made In China

VEVOR[®]
TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate
www.vevor.com/support

Instruction Manual of LH40-2 Pyrography Machine



1) Pyrography machine switch: Turn on the switch when using it, and turn it off when not in use to avoid danger.

2) Temperature regulator: is to adjust the temperature of wood burning pen, low temperature rendering to adjust the temperature in the light gray area, the red area is the high temperature area, the high temperature area is mainly the line painting effect.

The adjustment of the temperature of the wood burning pen is slowly adjusted by the thermostat, first of all, the temperature is adjusted to about 600 degrees and then slowly adjusted to a lower place, the best temperature is about 300-500 degrees. Low temperature rendering is best used in the range of 250-400 degrees. When rendering temperature adjustment, watching wood burning pen can burn light colors on the material, the temperature at this time is the best rendering effect (different material density and humidity need different optimal temperatures, please be patient to debug). You can draw the color painting with different shades and layers over and over again. If the temperature is too high, it is difficult to render the delicate picture effect. When tracing the line, the temperature can be appropriately increased, and smooth lines can be drawn according to your own situation. If you want to bake the line well, you should learn to slow down the pen at low temperature. The lower the temperature of the burning wood used, the slower the writing pen, the better the painting effect.

3) Thermometer: The temperature of the pyrography machine is adjusted by adjusting the Temperature value, and the temperature adjustment display range is 250-700 degrees.

4) pyrograph pen socket: Two with dual port configuration, press the button to quickly change pens. The pyrograph pen plug should be closely matched with the socket, the plug should be inserted into the bottom of the socket, which should be closely matched to avoid overheating and burning accessories.

5) Conversion switch: When using the A-point wood burning pen, press |, and the A-point wood burning pen will be powered on and immediately generate heat. When using the B-point wood burning pen, press ||, and the B-point wood burning pen will be powered on and immediately generate heat.

Note for pyrography machine:

1) Tighten the screw of the pen tip when applying the pen tip, avoid poor contact between the pen tip and the terminal so that the pen tip is not hot. The overheating of the terminal will burn out the accessories, if the terminal is too hot, that is the pen tip is not tightly fastened, and it should be fastened with a screwdriver in time.

2) Select a heating wire under 1 mm as the pen tip. Do not choose other non-heating wire materials such as iron wire as the pen tip, which is very dangerous and easy to burn out all the accessories in the movement, and it is easy to cause electric shock and fire. movement, and it is very easy to get electric shock and fire.

Instructions for using the wood burning wire tip

1) The function of the bent shape wire pen tip is introduced



No. 1 No. 5 No. 9 No. 12 No. 14 No. 16 No. 19 No. 21 No. 22 No. 23 No. 24 No. 27 No. 28 No. 30

Tips for using a bent metal wire pen tip. The main function of a bent pen tip is to trace lines and render small areas of silk hair. When tracing lines, the blue indicator on the temperature control knob points towards around 250C-350C. Slowly move the pen and do not move too fast. Look at the smooth edges of the line color, and the entire line color should be uniform and just right. When rendering, adjust the temperature to around 220C-300 °C, and draw hair fine lines at a temperature of around 250 °C -350C.

2) Pointed flat shape of metal wire pen head function introduction



No. 2 No. 7 No. 11 No. 18 No. 26

Tips for using pointed metal wire pen tips: Pointed pen tips mainly focus on drawing fine lines and rendering fine parts. The temperature for drawing fine lines is 220-250 °C, and the temperature for rendering fine parts is 220-230 °C. When rendering, it is best to watch the color change slightly on the gourd and wooden board, and gradually deepen the color so that the color is delicate and rich. Dark color rendering is best at around 300 °C.

3) Flat shape wire pen tip function introduction



No. 3 No. 4 No. 6 No. 8 No. 10 No. 13 No. 15 No. 17 No. 20 No. 25 No. 29

The flat metal wire pen head is mainly used for flat rendering and side silk line drawing. The temperature for flat rendering is around 220C-290 °C for light colors, and 300C-400 °C for dark colors.

Summary: The temperature of the pen head introduced earlier should not be too dogmatic and rigid. Depending on the density, humidity, and hardness of the material used for soldering, the temperature required for soldering may vary. You can learn from and adjust the experiment flexibly to find the most suitable temperature for yourself. Whether it's writing, tracing, or rendering, if you want good results, you would rather use the pen slowly at low temperatures to deepen layer by layer. Never use a pen quickly at high temperatures. It is difficult to see works with uneven lines, uneven rendering colors, uneven depth, rough and delicate images.

Correct installation of pen point of pyrography


The pen point of pyrograph is not hot, and the temperature is suddenly high, and suddenly low. There are sparks coming from the pen point and the penholder is hot to grasp. What are the reasons? It's because the incorrect installation of the pen point.



1
Unscrew both screws on the pen and detach them from the hole where the pen head is installed, making it easier for the pen head to be inserted smoothly to the bottom. The effect is shown in the above picture.



2
The picture above correctly shows the effect by inserting the two pins of the pen tip into the bottom of the hole inside.







3
Finally, tighten the two screws with appropriate torque, be sure to tighten.






4
Screw does not hold pen tip two pins, error! The pen tip does not heat up properly.

there are some symptoms of the incorrect installation of pen point , which are the abnormal heat of pen point , unstable temperature of pen point , sparks generating from the pen point, the heating of copper column and the burning hot of pen holder.

Tips for using wood burning pen tips



Tips for using wood burning tools and knives



Precautions for using a pyrography pen holder

When using a pyrography pen, the temperature of the pen tip is very high. When placing the pen in the holder, it is important to avoid the high-temperature pen tip coming into contact with the holder to avoid burning it out. When placing the pen on the holder, use the pen holder to contact and fix the pyrography brush. It is forbidden for the high-temperature pen tip to come into contact with any part of the holder.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Supporto tecnico e certificato di garanzia elettronica www.vevor.com/support

MACCHINA PIROGRAFO

Continuiamo a impegnarci per fornirvi strumenti a prezzi competitivi.

"Risparmia la metà", "Metà prezzo" o qualsiasi altra espressione simile da noi utilizzata rappresenta solo una stima del risparmio che potresti ottenere acquistando determinati utensili con noi rispetto ai principali marchi principali e non necessariamente intende coprire tutte le categorie di utensili da noi offerti. Ti ricordiamo cortesemente di verificare attentamente quando effettui un ordine con noi se stai effettivamente risparmiando la metà rispetto ai principali marchi principali.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

MACCHINA PIROGRAFO

MODELLO:LH50








HAI BISOGNO DI AIUTO? CONTATTACI!

Hai domande sui prodotti? Hai bisogno di supporto tecnico? Non esitare a contattarci:

**Supporto tecnico e certificato di garanzia
elettronica www.vevor.com/support**

Questa è l'istruzione originale, si prega di leggere attentamente tutte le istruzioni del manuale prima di utilizzare. VEVOR si riserva una chiara interpretazione del nostro manuale utente. L'aspetto del prodotto sarà soggetto al prodotto ricevuto. Vi preghiamo di perdonarci se non vi informeremo di nuovo se ci sono aggiornamenti tecnologici o software sul nostro prodotto.

	<p>Attenzione: per ridurre il rischio di lesioni, l'utente deve leggere attentamente il manuale di istruzioni.</p>
	<p>DICHIARAZIONE FCC</p> <p>Questo dispositivo è conforme alla Parte 15 delle Norme FCC. Il funzionamento è soggetto alle due condizioni seguenti: (1) Questo dispositivo non può causare interferenze dannose e (2) Questo dispositivo deve accettare qualsiasi interferenza ricevuta, comprese le interferenze che possono causare un funzionamento indesiderato.</p>
	<p>SMALTIMENTO CORRETTO</p> <p>Questo prodotto è soggetto alle disposizioni della Direttiva Europea 2012/19/CE. Il simbolo raffigurante un bidone della spazzatura barrato indica che il prodotto richiede la raccolta differenziata dei rifiuti nell'Unione Europea. Ciò si applica al prodotto e a tutti gli accessori contrassegnati con questo simbolo. I prodotti contrassegnati come tali potrebbero non essere smaltiti insieme ai normali rifiuti domestici, ma deve essere portato in un punto di raccolta per il riciclaggio di apparecchiature elettriche ed elettroniche</p>
	<p>Questo simbolo, posto prima di un commento sulla sicurezza, indica un tipo di precauzione, avviso o pericolo. Ignorare questo avviso può causare un incidente. Si prega di seguire sempre la raccomandazione di seguito per ridurre il rischio di lesioni, incendi o folgorazione.</p>
	<p>Questo prodotto è di classe di protezione II. Ciò significa che è dotato di isolamento migliorato o doppio.</p>

IMPORTANTI MISURE DI SICUREZZA

AVVERTIMENTO:

1. Le avvertenze devono essere seguite attentamente per evitare lesioni personali. Un uso improprio può causare scosse elettriche, incendi, lesioni personali e altri danni:

- 1) Tenere la macchina scollegata quando la si sposta.
- 2) Durante l'installazione degli accessori, tenere la spina scollegata.
- 3) Posizionare su una piattaforma piana e stabile e operare in condizioni di ventilazione.
- 4) Indossare speciali dispositivi di protezione durante l'uso della macchina.
- 5) Non utilizzare questa macchina in luoghi pericolosi.
- 6) Utilizzarlo solo quando la macchina funziona correttamente.
- 7) Non smontare e riparare questa macchina.
- 8) Non utilizzare una presa CA non adatta.
- 9) Non toccare la piastra riscaldante quando la macchina è in fase di riscaldamento.
- 10) Non utilizzare in ambienti umidi o a contatto con l'acqua. Inoltre, non infiltrare liquido nella macchina per prevenire incendi o scosse elettriche causate da un cortocircuito circuito.
- 11) Non utilizzare un alimentatore che non soddisfi la tensione nominale. L'alimentatore Un'alimentazione che non soddisfa la tensione specificata può causare incendi o scosse elettriche.
- 12) Assicurarsi che la macchina sia collegata a terra per non causare danni alla persona.
- 13) Non toccare l'asta rotante o la parte del cuscinetto con le dita durante l'uso in caso di lesioni.
- 14) Se la macchina non viene utilizzata per un lungo periodo, scollegare il cavo di alimentazione dalla presa di corrente. la presa.
- 15) Non utilizzare la macchina durante temporali o fulmini per evitare danni alla macchina.
- 16) Posizionare la macchina in modo uniforme sul tavolo ignifugo e tenerla lontana da oggetti infiammabili ed esplosivi.
- 17) Si prega di interrompere l'utilizzo se la macchina fuma, emette un odore particolare o diventa rumorosi e in altre condizioni anomale.
- 18) Questo apparecchio può essere utilizzato da bambini di età pari o superiore a 8 anni e da persone con ridotte capacità fisiche, sensoriali o mentali o mancanza di esperienza e conoscenza se hanno ricevuto supervisione o istruzioni riguardanti l'uso dell'apparecchio in modo sicuro e comprendere i pericoli coinvolti. I bambini non devono giocare con

l'apparecchio. La pulizia e la manutenzione da parte dell'utente non devono essere eseguite da bambini senza supervisione.


2. Attacco tipo Y: se il cavo di alimentazione è danneggiato, deve essere sostituito dal produttore, dal suo agente di assistenza o da persone ugualmente qualificate per evitare pericoli.

3. Per evitare pericoli dovuti al ripristino involontario del dispositivo di protezione termica, questo l'apparecchio non deve essere alimentato tramite un dispositivo di commutazione esterno, come un timer, o collegato a un circuito che viene regolarmente acceso e spento dalla società di servizi.

4. Nel processo di regolazione della temperatura, ci sarà un leggero ritardo nel display digitale temperatura, che è un fenomeno normale, attendere un momento.

SALVA QUESTE ISTRUZIONI

Manuale di istruzioni della macchina LPirografo



1) Interruttore della macchina pirografica: accendere l'interruttore quando la si utilizza e spegnerla quando non in uso per evitare pericoli.

2) Termostato: viene utilizzato per regolare la temperatura della penna pirografica. La luce la parte grigia è la normale regolazione della temperatura di rendering e la parte rossa è l'area ad alta temperatura. La regolazione della temperatura del riscaldamento elettrico

la penna a filo è quella di regolare lentamente la temperatura tramite il regolatore di temperatura. Se è la visualizzazione della temperatura, regolare la temperatura a 700 gradi e quindi abbassarla lentamente, sarebbe meglio che la temperatura fosse di circa 350-600 gradi e la resa a bassa temperatura fosse di circa 350-450 gradi. Quando si regola la temperatura, regolare la punta della penna a filo elettrico riscaldante da un po' di arancione grigiastro a non rosso. Non essere troppo rosso, una temperatura troppo alta renderà la penna morbida e incapace di disegnare normalmente, le prestazioni caleranno bruscamente e la linea tracciata verrà bruciata. 3) Presa per penna pirografica: la spina della penna pirografica deve essere abbinata strettamente alla presa, la spina deve essere inserita nella parte inferiore della presa, che deve essere abbinata strettamente per evitare il surriscaldamento e la combustione degli accessori

Termometro: la temperatura della macchina pirografica viene regolata regolando il valore della temperatura e l'intervallo di visualizzazione della regolazione della temperatura è compreso tra 300 e 700 gradi.


Precauzioni per la macchina pirografica: 1)

Stringere la vite della punta della penna quando si applica la punta della penna, evitare un contatto inadeguato tra la punta della penna e il terminale in modo che la punta della penna non sia calda. Il surriscaldamento del terminale brucerà gli accessori. Se il terminale è troppo caldo, significa che la punta della penna non è fissata saldamente e deve essere fissata in tempo con un cacciavite.


2) Selezionare un filo riscaldante inferiore a 1 mm come punta della penna. Non scegliere altri materiali di filo non riscaldanti come il filo di ferro come punta della penna, che è molto pericoloso e può facilmente bruciare tutti gli accessori nel movimento, ed è facile causare scosse elettriche e incendi.

Corretta installazione della punta della penna del pirografo

La punta della penna del pirografo non è calda, e la temperatura è improvvisamente alta, e improvvisamente bassa. Ci sono scintille che escono dalla punta della penna e il portapenne è caldo da impugnare. Quali sono le ragioni? È a causa dell'installazione non corretta della punta della penna.




Questa vite superiore deve uscire per più di 4 mm e la vite deve uscire questa distanza e si inserisce nella punta della penna. È sbagliato che la vite si inserisca nella punta della penna a questa distanza.




I piedini della punta della penna devono essere inseriti nel morsetto di rame per ulteriori di 8 mm.

Il morsetto di rame con punta di penna



Stringere la vite con il cacciavite e stringere i piedini della punta della penna! deve essere ben chiuso; altrimenti la punta della penna non si riscalda o il suo riscaldamento è anormale o addirittura scintille.

La vite perde troppo all'esterno, ed è sicuro che i piedi della punta della penna non sono serrato, il che è sbagliato.



È essenziale installare correttamente la punta della penna.

ci sono alcuni sintomi dell'installazione non corretta della punta della penna, che sono i
calore anomalo della punta della penna, temperatura instabile della punta della penna, formazione di scintille
dalla punta della penna, dal riscaldamento della colonna di rame e dal calore bruciante della penna
titolare.

Dati tecnici


Modello	LH50	
Tensione nominale	120V- 60Hz per gli Stati Uniti	220-240V- 50Hz Per UE o AU
Potenza	20W	

Made in China

VEVOR®
TOUGH TOOLS, HALF PRICE

Supporto tecnico e certificato di garanzia
elettronica www.vevor.com/support

Instruction Manual of LH40-2 Pyrography Machine



The adjustment of the temperature of the wood burning pen is slowly adjusted by the thermostat, first of all, the temperature is adjusted to about 600 degrees and then slowly adjusted to a lower place, the best temperature is about 300-500 degrees. Low temperature rendering is best used in the range of 250-400 degrees. When rendering temperature adjustment, watching wood burning pen can burn light colors on the material, the temperature at this time is the best rendering effect (different material density and humidity need different optimal temperatures, please be patient to debug). You can draw the color painting with different shades and layers over and over again. If the temperature is too high, it is difficult to render the delicate picture effect. When tracing the line, the temperature can be appropriately increased, and smooth lines can be drawn according to your own situation. If you want to bake the line well, you should learn to slow down the pen at low temperature. The lower the temperature of the burning wood used, the slower the writing pen, the better the painting effect.

3) Thermometer: The temperature of the pyrography machine is adjusted by adjusting the Temperature value, and the temperature adjustment display range is 250-700 degrees.

4) pyrograph pen socket: Two with dual port configuration, press the button to quickly change pens. The pyrograph pen plug should be closely matched with the socket, the plug should be inserted into the bottom of the socket, which should be closely matched to avoid overheating and burning accessories.

5) Conversion switch: When using the A-point wood burning pen, press |, and the A-point wood burning pen will be powered on and immediately generate heat. When using the B-point wood burning pen, press ||, and the B-point wood burning pen will be powered on and immediately generate heat.

Note for pyrography machine:

1) Tighten the screw of the pen tip when applying the pen tip, avoid poor contact between the pen tip and the terminal so that the pen tip is not hot. The overheating of the terminal will burn out the accessories, If the terminal is too hot, that is the pen tip is not tightly fastened, and it should be fastened with a screwdriver in time.

2) Select a heating wire under 1 mm as the pen tip. Do not choose other non-heating wire materials such as iron wire as the pen tip, which is very dangerous and easy to burn out all the accessories in the movement, and it is easy to cause electric shock and fire. movement, and it is very easy to get electric shock and fire.

Instructions for using the wood burning wire tip

1) The function of the bent shape wire pen tip is introduced



No. 1 No. 5 No. 9 No. 12 No. 14 No. 16 No. 19 No. 21 No. 22 No. 23 No. 24 No. 27 No. 28 No. 30

Tips for using a bent metal wire pen tip. The main function of a bent pen tip is to trace lines and render small areas of silk hair. When tracing lines, the blue indicator on the temperature control knob points towards around 250C-350C. Slowly move the pen and do not move too fast. Look at the smooth edges of the line color, and the entire line color should be uniform and just right. When rendering, adjust the temperature to around 220C-300 °C, and draw hair fine lines at a temperature of around 250 °C -350C.

2) Pointed flat shape of metal wire pen head function introduction



No. 2 No. 7 No. 11 No. 18 No. 26

Tips for using pointed metal wire pen tips: Pointed pen tips mainly focus on drawing fine lines and rendering fine parts. The temperature for drawing fine lines is 220-250 °C, and the temperature for rendering fine parts is 220-230 °C. When rendering, it is best to watch the color change slightly on the gourd and wooden board, and gradually deepen the color so that the color is delicate and rich. Dark color rendering is best at around 300 °C.

3) Flat shape wire pen tip function introduction



No. 3 No. 4 No. 6 No. 8 No. 10 No. 13 No. 15 No. 17 No. 20 No. 25 No. 29

The flat metal wire pen head is mainly used for flat rendering and side silk line drawing. The temperature for flat rendering is around 220C-290 °C for light colors, and 300C-400 °C for dark colors.

Summary: The temperature of the pen head introduced earlier should not be too dogmatic and rigid. Depending on the density, humidity, and hardness of the material used for soldering, the temperature required for soldering may vary. You can learn from and adjust the experiment flexibly to find the most suitable temperature for yourself. Whether it's writing, tracing, or rendering, if you want good results, you would rather use the pen slowly at low temperatures to deepen layer by layer. Never use a pen quickly at high temperatures. It is difficult to see works with uneven lines, uneven rendering colors, uneven depth, rough and delicate images.

Correct installation of pen point of pyrography

The pen point of pyrograph is not hot, and the temperature is suddenly high, and suddenly low. There are sparks coming from the pen point and the penholder is hot to grasp. What are the reasons? It's because the incorrect installation of the pen point.



1
Unscrew both screws on the pen and detach them from the hole where the pen head is installed, making it easier for the pen head to be inserted smoothly to the bottom. The effect is shown in the above picture.



2
The picture above correctly shows the effect by inserting the two pins of the pen tip into the bottom of the hole inside.







3
Finally, tighten the two screws with appropriate torque, be sure to tighten.







4
Screw does not hold pen tip two pins, error! The pen tip does not heat up properly.

there are some symptoms of the incorrect installation of pen point , which are the abnormal heat of pen point , unstable temperature of pen point , sparks generating from the pen point, the heating of copper column and the burning hot of pen holder.

Tips for using wood burning pen tips



Tips for using wood burning tools and knives



Precautions for using a pyrography pen holder

When using a pyrography pen, the temperature of the pen tip is very high. When placing the pen in the holder, it is important to avoid the high-temperature pen tip coming into contact with the holder to avoid burning it out. When placing the pen on the holder, use the pen holder to contact and fix the pyrography brush. It is forbidden for the high-temperature pen tip to come into contact with any part of the holder.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Wsparcie techniczne i certyfikat gwarancji elektronicznej www.vevor.com/support

MASZYNA PIROGRAFOWA

Nadal staramy się oferować Państwu narzędzia w konkurencyjnych cenach.

„Oszczędź połowę”, „Połowa ceny” lub inne podobne wyrażenia używane przez nas stanowią jedynie szacunkowe oszczędności, jakie możesz uzyskać kupując u nas określone narzędzia w porównaniu z głównymi markami i niekoniecznie oznaczają one objęcie wszystkich kategorii narzędzi oferowanych przez nas. Uprzejmie przypominamy, aby dokładnie sprawdzić, czy składając u nas zamówienie faktycznie oszczędzasz połowę w porównaniu z głównymi markami.

VEVOR[®]
TOUGH TOOLS, HALF PRICE

MASZYNA PIROGRAFOWA

MODEL:LH50








POTRZEBUJESZ POMOCY? SKONTAKTUJ SIĘ Z NAMI!

Masz pytania dotyczące produktu? Potrzebujesz wsparcia technicznego? Skontaktuj się z nami:

Wsparcie techniczne i certyfikat gwarancji
elektronicznej www.vevor.com/support

To jest oryginalna instrukcja, przed użyciem należy uważnie przeczytać wszystkie instrukcje. VEVOR zastrzega sobie jasną interpretację naszej instrukcji obsługi. Wygląd produktu będzie zależał od produktu, który otrzymałeś. Prosimy o wybaczenie, że nie poinformujemy Cię ponownie, jeśli w naszym produkcie pojawią się jakiegokolwiek aktualizacje technologiczne lub oprogramowania.

	<p>Ostrzeżenie: Aby zminimalizować ryzyko obrażeń, użytkownik powinien uważnie przeczytać instrukcję obsługi.</p>
	<p>OŚWIADCZENIE FCC</p> <p>To urządzenie jest zgodne z częścią 15 przepisów FCC. Jego działanie podlega następującym dwóm warunkom: (1) To urządzenie nie może powodować szkodliwych zakłóceń i (2) to urządzenie musi akceptować wszelkie odbierane zakłócenia, w tym zakłócenia, które mogą powodować niepożądane działanie.</p>
	<p>PRAWIDŁOWA UTYLIZACJA</p> <p>Ten produkt podlega postanowieniom Dyrektywy Europejskiej 2012/19/WE. Symbol przedstawiający przekreślony kosz na śmieci na kółkach oznacza, że produkt wymaga oddzielnej zbiórki odpadów w Unii Europejskiej. Dotyczy to produktu i wszystkich akcesoriów oznaczonych tym symbolem. Produkty oznaczone w ten sposób nie mogą być wyrzucać razem z normalnymi odpadami domowymi, lecz należy je oddać do punktu zbiórki odpadów. punkt zbiórki sprzętu elektrycznego i elektronicznego do recyklingu</p>
	<p>Ten symbol, umieszczony przed komentarzem dotyczącym bezpieczeństwa, wskazuje na rodzaj środka ostrożności, ostrzeżenia lub niebezpieczeństwa. Zignorowanie tego ostrzeżenia może doprowadzić do wypadku. Zawsze postępuj zgodnie z poniższymi zaleceniami, aby zmniejszyć ryzyko obrażeń, pożaru lub porażenia prądem.</p>
	<p>Ten produkt ma klasę ochrony II. Oznacza to, że jest wyposażony w wzmocniona lub podwójna izolacja.</p>

WAŻNE ZABEZPIECZENIA

OSTRZEŻENIE:

1. Należy uważnie przestrzegać ostrzeżeń, aby uniknąć obrażeń ciała. Niewłaściwe użycie może spowodować porażenie prądem, pożar, obrażenia ciała i inne szkody:

- 1) Odłącz urządzenie od zasilania podczas przenoszenia.
- 2) Odłącz urządzenie od zasilania podczas montażu akcesoriów.
- 3) Umieścić na płaskiej i stabilnej platformie i używać w wentylowanych warunkach.
- 4) Podczas obsługi maszyny należy nosić specjalny sprzęt ochronny.
- 5) Nie używaj tego urządzenia w miejscach niebezpiecznych.
- 6) Używaj urządzenia tylko wtedy, gdy działa prawidłowo.

7) Nie rozbieraj i nie naprawiaj tego urządzenia.

8) Nie używaj nieodpowiedniego gniazdka sieciowego.

9) Nie dotykaj płyty grzewczej podczas nagrzewania się urządzenia.

10) Nie stosować w wilgotnym środowisku lub w kontakcie z wodą. Nie należy również

włączyć płyn do maszyny, aby zapobiec pożarowi lub porażeniu prądem elektrycznym spowodowanemu zwarcie
okrężenie.

11) Nie używaj zasilacza, który nie spełnia napięcia znamionowego.

Zasilanie o napięciu innym niż określone w specyfikacji może spowodować pożar lub porażenie prądem.

12) Upewnij się, że maszyna jest uziemiona, aby nie spowodować obrażeń ciała.

13) Podczas użytkowania nie dotykaj palcami obracającego się pręta ani łożyska.

w przypadku obrażeń.

14) Jeżeli urządzenie nie będzie używane przez dłuższy czas, należy odłączyć przewód zasilający od gniazdka.
gniazdo.

15) Nie używaj urządzenia podczas burzy lub wyładowań atmosferycznych, aby uniknąć uszkodzenia
maszyna.

16) Ustawić maszynę równomiernie na stole ognioodpornym i trzymać z dala od
materiały łatwopalne i wybuchowe.

17) Należy zaprzestać korzystania z urządzenia, jeżeli zaczyna ono dymić, wydzielać dziwny zapach lub ulega uszkodzeniu.
w hałaśliwych warunkach i innych nietypowych warunkach.

18) Z urządzenia mogą korzystać dzieci w wieku od 8 lat oraz osoby

o ograniczonej sprawności fizycznej, sensorycznej lub umysłowej lub braku doświadczenia i
wiedzy, jeżeli zapewniono im nadzór lub instruktaż dotyczący korzystania z

urządzenie w bezpieczny sposób i zrozumieć związane z tym zagrożenia. Dzieci nie powinny bawić się

urządzenia. Czyszczenie i konserwacja użytkownika nie mogą być wykonywane przez dzieci bez nadzór.

2. Typ Y: W przypadku uszkodzenia przewodu zasilającego należy go wymienić na nowy.


producenta, jego przedstawiciela serwisowego lub podobnie wykwalifikowaną osobę w celu uniknięcia zagrożenia.

3. Aby uniknąć zagrożenia wynikającego z przypadkowego zresetowania wyłącznika termicznego, urządzenia nie wolno zasilac za pomocą zewnętrznego urządzenia przełączającego, takiego jak timer, lub podłączony do obwodu, który jest regularnie włączany i wyłączany przez dostawcę energii.

4. Podczas regulacji temperatury może wystąpić niewielkie opóźnienie w wyświetlaniu wartości cyfrowych. temperatury, co jest zjawiskiem normalnym, proszę chwilę poczekać.

ZAPISZ TE INSTRUKCJE

Instrukcja obsługi maszyny LPyrograph



1) Przełącznik pirografu: Włącz przełącznik podczas korzystania z niego i wyłącz go gdy nie są używane, aby uniknąć niebezpieczeństwa.

2) Termostat: Służy do regulacji temperatury pirografu. Światło szara część to normalna regulacja temperatury renderowania, a czerwona część jest obszarem o wysokiej temperaturze. Regulacja temperatury ogrzewania elektrycznego

długopis z drutu ma powoli regulować temperaturę za pomocą regulatora temperatury. Jeśli jest to wyświetlacz temperatury, ustaw temperaturę na 700 stopni, a następnie powoli ją obniż, najlepiej byłoby, gdyby temperatura wynosiła około 350-600 stopni, a niska temperatura wynosiła około 350-450 stopni. Podczas regulacji temperatury dostosuj końcówkę długopisu z drutu grzewczego z lekko szarawo-pomarańczowego na nieczerwony. Nie bądź zbyt czerwony, zbyt wysoka temperatura sprawi, że długopis stanie się miękki i nie będzie można rysować normalnie, wydajność gwałtownie spadnie, a narysowana linia zostanie spalona.

3) gniazdo długopisu pirograficznego: Wtyczka długopisu pirograficznego powinna być ściśle dopasowana do gniazda, wtyczka powinna być włożona do dolnej części gniazda, które powinno być ściśle dopasowane, aby uniknąć przegrzania i spalania akcesoriów

Termometr: Temperaturę pirografu reguluje się poprzez zmianę wartości temperatury. Zakres wyświetlania temperatury wynosi 300-700 stopni.


Środki ostrożności dotyczące pirografu: 1)

Dokręć śrubę końcówki pióra podczas zakładania końcówki pióra, unikaj słabego kontaktu między końcówką pióra a terminalem, aby końcówka pióra nie była gorąca. Przegrzanie terminala spowoduje spalanie akcesoriów. Jeśli terminal jest zbyt gorący, oznacza to, że końcówka pióra nie jest mocno zamocowana. Należy ją w odpowiednim czasie dokręcić śrubokrętem.

2) Wybierz drut grzewczy o średnicy poniżej 1 mm jako końcówkę pióra. Nie wybieraj innych materiałów nienagrzewających się, takich jak drut żelazny, jako końcówkę pióra, ponieważ jest to bardzo niebezpieczne i łatwo może spowodować spalanie wszystkich akcesoriów w ruchu, a ponadto jest to łatwe spowodować porażenie prądem i pożar.


Prawidłowy montaż końcówki pióra pirografu

Końcówka pióra pirografu nie jest gorąca, a temperatura jest nagle wysoka i nagle niska. Z końcówki pióra wydobywają się iskry, a uchwyt pióra jest gorący do uchwycenia. Jakże są tego przyczyny? Powodem jest nieprawidłowa instalacja końcówki pióra.




Tutaj górna śruba musi wyjść na więcej niż 4 mm, a śruba musi wyjść tej odległości i wsuwa się ją do końcówki pióra.

Niewłaściwe jest wsuwanie śruby do końcówki pióra w tej odległości.



Nóżki końcówki pióra należy włożyć do miedzianego zacisku, aby zapewnić większą stabilność. niż 8 mm.


Końcówka miedziana do długopisu



Dokręć śrubę śrubokrętem i dokręć nóżki końcówki pióra!

musi być szczelnie zamknięty; w przeciwnym razie końcówka pióra nie będzie się nagrzewać lub jej nagrzewanie będzie nieprawidłowe lub nawet iskrzenie.

Śruba przecieka zbyt mocno na zewnątrz , i na pewno nie ma tu miejsca na końcówki długopisów dokręcone, co jest nie tak.



Prawidłowe zamontowanie końcówki pióra jest kluczowe.

Istnieją pewne objawy nieprawidłowego montażu końcówki pióra, którymi są:
nienormalne ciepło końcówki pióra, niestabilna temperatura końcówki pióra, generowanie iskier od końcówki pióra, nagrzewania się miedzianej kolumny i palącego gorąca pióra uchwyt.

Dane techniczne


Model	LH50	
Napięcie znamionowe	120 V~ 60 Hz dla USA	220-240 V~ 50 Hz dla UE lub AU
Potęga	20 W	

Wyprodukowano w Chinach

VEVOR®
TOUGH TOOLS, HALF PRICE

Wsparcie techniczne i certyfikat gwarancji
elektronicznej www.vevor.com/support

Instruction Manual of LH40-2 Pyrography Machine



1) Pyrography machine switch: Turn on the switch when using it, and turn it off when not in use to avoid danger.

2) Temperature regulator: is to adjust the temperature of wood burning pen, low temperature rendering to adjust the temperature in the light gray area, the red area is the high temperature area, the high temperature area is mainly the line painting effect.

The adjustment of the temperature of the wood burning pen is slowly adjusted by the thermostat, first of all, the temperature is adjusted to about 600 degrees and then slowly adjusted to a lower place, the best temperature is about 300-500 degrees. Low temperature rendering is best used in the range of 250-400 degrees. When rendering temperature adjustment, watching wood burning pen can burn light colors on the material, the temperature at this time is the best rendering effect (different material density and humidity need different optimal temperatures, please be patient to debug). You can draw the color painting with different shades and layers over and over again. If the temperature is too high, it is difficult to render the delicate picture effect. When tracing the line, the temperature can be appropriately increased, and smooth lines can be drawn according to your own situation. If you want to bake the line well, you should learn to slow down the pen at low temperature. The lower the temperature of the burning wood used, the slower the writing pen, the better the painting effect.

3) Thermometer: The temperature of the pyrography machine is adjusted by adjusting the Temperature value, and the temperature adjustment display range is 250-700 degrees.

4) pyrograph pen socket: Two with dual port configuration, press the button to quickly change pens. The pyrograph pen plug should be closely matched with the socket, the plug should be inserted into the bottom of the socket, which should be closely matched to avoid overheating and burning accessories.

5) Conversion switch: When using the A-point wood burning pen, press |, and the A-point wood burning pen will be powered on and immediately generate heat. When using the B-point wood burning pen, press ||, and the B-point wood burning pen will be powered on and immediately generate heat.

Note for pyrography machine:

1) Tighten the screw of the pen tip when applying the pen tip, avoid poor contact between the pen tip and the terminal so that the pen tip is not hot. The overheating of the terminal will burn out the accessories, If the terminal is too hot, that is the pen tip is not tightly fastened, and it should be fastened with a screwdriver in time.

2) Select a heating wire under 1 mm as the pen tip. Do not choose other non-heating wire materials such as iron wire as the pen tip, which is very dangerous and easy to burn out all the accessories in the movement, and it is easy to cause electric shock and fire. movement, and it is very easy to get electric shock and fire.

Instructions for using the wood burning wire tip

1) The function of the bent shape wire pen tip is introduced



Tips for using a bent metal wire pen tip. The main function of a bent pen tip is to trace lines and render small areas of silk hair. When tracing lines, the blue indicator on the temperature control knob points towards around 250C-350C. Slowly move the pen and do not move too fast. Look at the smooth edges of the line color, and the entire line color should be uniform and just right. When rendering, adjust the temperature to around 220C-300 °C, and draw hair fine lines at a temperature of around 250 °C -350C.

2) Pointed flat shape of metal wire pen head function introduction



Tips for using pointed metal wire pen tips: Pointed pen tips mainly focus on drawing fine lines and rendering fine parts. The temperature for drawing fine lines is 220-250 °C, and the temperature for rendering fine parts is 220-230 °C. When rendering, it is best to watch the color change slightly on the gourd and wooden board, and gradually deepen the color so that the color is delicate and rich. Dark color rendering is best at around 300 °C.

3) Flat shape wire pen tip function introduction



The flat metal wire pen head is mainly used for flat rendering and side silk line drawing. The temperature for flat rendering is around 220C-290 °C for light colors, and 300C-400 °C for dark colors.

Summary: The temperature of the pen head introduced earlier should not be too dogmatic and rigid. Depending on the density, humidity, and hardness of the material used for soldering, the temperature required for soldering may vary. You can learn from and adjust the experiment flexibly to find the most suitable temperature for yourself. Whether it's writing, tracing, or rendering, if you want good results, you would rather use the pen slowly at low temperatures to deepen layer by layer. Never use a pen quickly at high temperatures. It is difficult to see works with uneven lines, uneven rendering colors, uneven depth, rough and delicate images.

Correct installation of pen point of pyrography

The pen point of pyrograph is not hot, and the temperature is suddenly high, and suddenly low. There are sparks coming from the pen point and the penholder is hot to grasp. What are the reasons? It's because the incorrect installation of the pen point.



1
Unscrew both screws on the pen and detach them from the hole where the pen head is installed, making it easier for the pen head to be inserted smoothly to the bottom. The effect is shown in the above picture.



2
The picture above correctly shows the effect by inserting the two pins of the pen tip into the bottom of the hole inside.







3
Finally, tighten the two screws with appropriate torque, be sure to tighten.







4
Screw does not hold pen tip two pins, error! The pen tip does not heat up properly.

there are some symptoms of the incorrect installation of pen point , which are the abnormal heat of pen point , unstable temperature of pen point , sparks generating from the pen point, the heating of copper column and the burning hot of pen holder.

Tips for using wood burning pen tips



Tips for using wood burning tools and knives

<p>This is a rendering of the wood burning just now. Later, we will demonstrate the usage techniques with a carving knife.</p>  <p>1</p>	<p>Use a carving knife to scrape off unwanted images or defects. When scraping, gently scrape and try to scrape as flat and smooth as possible.</p>  <p>2</p>
<p>Techniques such as using a carving knife to scrape out highlights, fine lines, and increase the brightness of local color tones in the image</p>  <p>3</p>	<p>1) Use tweezers to clamp and adjust the angle of the pen head. The default angle of the factory made pen head is relatively small. When increasing the angle of the pen head, first set the temperature to the highest. When the pen head turns red and has good plasticity, use tweezers to clamp and bend the angle of the pen head. 2) When replacing the pen tip, it is very hot and can easily burn the skin. It is safer to replace it with tweezers.</p> 

Precautions for using a pyrography pen holder

When using a pyrography pen, the temperature of the pen tip is very high. When placing the pen in the holder, it is important to avoid the high-temperature pen tip coming into contact with the holder to avoid burning it out. When placing the pen on the holder, use the pen holder to contact and fix the pyrography brush. It is forbidden for the high-temperature pen tip to come into contact with any part of the holder.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technischer Support und E-Garantie-Zertifikat www.vevor.com/support

Pyrograph-Maschine

Wir sind weiterhin bestrebt, Ihnen Werkzeuge zu wettbewerbsfähigen Preisen anzubieten.

„Sparen Sie die Hälfte“, „Halber Preis“ oder andere ähnliche Ausdrücke, die wir verwenden, stellen nur eine Schätzung der Ersparnis dar, die Sie beim Kauf bestimmter Werkzeuge bei uns im Vergleich zu den großen Topmarken erzielen können, und bedeuten nicht notwendigerweise, dass sie alle von uns angebotenen

Werkzeugkategorien abdecken. Wir möchten Sie freundlich daran erinnern, bei Ihrer Bestellung bei uns sorgfältig zu prüfen, ob Sie im Vergleich zu den großen Topmarken tatsächlich die Hälfte sparen.

VEVOR[®]
TOUGH TOOLS, HALF PRICE

Pyrograph-Maschine

MODELL:LH50








Brauchen Sie Hilfe? Kontaktieren Sie uns!

Sie haben Fragen zu unseren Produkten? Sie benötigen technischen Support? Dann kontaktieren Sie uns gerne:

Technischer Support und E-Garantie-Zertifikat
www.vevor.com/support

Dies ist die Originalanleitung. Bitte lesen Sie alle Anweisungen sorgfältig durch, bevor Sie das Gerät in Betrieb nehmen. VEVOR behält sich eine klare Auslegung unserer Bedienungsanleitung vor. Das Erscheinungsbild des Produkts richtet sich nach dem Produkt, das Sie erhalten haben. Bitte verzeihen Sie uns, dass wir Sie nicht erneut informieren, wenn es Technologie- oder Software-Updates für unser Produkt gibt.

	<p>Warnung: Um das Verletzungsrisiko zu verringern, muss der Benutzer die Bedienungsanleitung sorgfältig lesen.</p>
	<p>FCC-ERKLÄRUNG</p> <p>Dieses Gerät entspricht Teil 15 der FCC-Bestimmungen. Der Betrieb unterliegt den folgenden beiden Bedingungen: (1) Dieses Gerät darf keine schädlichen Störungen verursachen und (2) dieses Gerät muss alle empfangenen Störungen akzeptieren, einschließlich Störungen, die einen unerwünschten Betrieb verursachen können.</p>
	<p>KORREKTE ENTSORGUNG</p> <p>Dieses Produkt unterliegt den Bestimmungen der europäischen Richtlinie 2012/19/EU. Das Symbol einer durchgestrichenen Mülltonne weist darauf hin, dass das Produkt in der Europäischen Union einer getrennten Müllentsorgung unterliegt. Dies gilt für das Produkt und alle mit diesem Symbol gekennzeichneten Zubehörteile. Produkte, die so gekennzeichnet sind, dürfen nicht nicht mit dem normalen Hausmüll entsorgt werden, sondern müssen an einen Sammelstelle für das Recycling von elektrischen und elektronischen Geräten</p>
	<p>Dieses Symbol vor einem Sicherheitshinweis weist auf eine Vorsichtsmaßnahme, Warnung oder Gefahr hin. Das Ignorieren dieser Warnung kann zu einem Unfall führen. Befolgen Sie immer die nachstehende Empfehlung, um das Risiko von Verletzungen, Bränden oder Stromschlägen zu verringern.</p>
	<p>Dieses Produkt ist in Schutzklasse II. Das heißt, es ist ausgestattet mit verstärkte oder doppelte Isolierung.</p>

WICHTIGE SICHERHEITSHINWEISE

WARNUNG:

1. Warnungen müssen sorgfältig befolgt werden, um Verletzungen zu vermeiden. Unsachgemäßer Gebrauch kann zu Stromschlag, Feuer, Verletzungen und anderen Schäden führen:

- 1) Lassen Sie die Maschine beim Transportieren vom Stromnetz getrennt.
- 2) Lassen Sie das Gerät während der Installation von Zubehör vom Stromnetz getrennt.
- 3) Auf einer flachen und stabilen Plattform platzieren und unter belüfteten Bedingungen betreiben.
- 4) Tragen Sie beim Betrieb der Maschine spezielle Schutzausrüstung.
- 5) Verwenden Sie diese Maschine nicht an gefährlichen Orten.
- 6) Nur verwenden, wenn die Maschine ordnungsgemäß funktioniert.
- 7) Zerlegen und reparieren Sie die Maschine nicht.
- 8) Verwenden Sie keine ungeeignete Steckdose.
- 9) Berühren Sie die Heizplatte nicht, während die Maschine aufheizt.
- 10) Nicht in feuchter Umgebung oder in Kontakt mit Wasser verwenden. Nicht Flüssigkeit in die Maschine eindringen, um Feuer oder Stromschlag durch einen Kurzschluss zu verhindern
Schaltung.
- 11) Verwenden Sie kein Netzteil, das die angegebene Spannung nicht erfüllt. Das Netzteil Eine Stromversorgung, die nicht die angegebene Spannung aufweist, kann zu Feuer oder Stromschlag führen.
- 12) Stellen Sie sicher, dass die Maschine geerdet ist, um Verletzungen vorzubeugen.
- 13) Berühren Sie die rotierende Stange oder das Lagerteil nicht mit den Fingern während des Gebrauchs in im Falle von Verletzungen.
- 14) Wenn Sie die Maschine längere Zeit nicht benutzen, ziehen Sie bitte den Netzstecker aus der die Buchse.
- 15) Benutzen Sie die Maschine nicht bei Gewitter oder Blitzeinschlag, um Schäden an der Maschine.
- 16) Stellen Sie die Maschine flach auf den feuerfesten Tisch und halten Sie sie von brennbare und explosive Gegenstände.
- 17) Bitte stellen Sie die Benutzung ein, wenn die Maschine raucht, einen eigenartigen Geruch abgibt oder laut und unter anderen anormalen Bedingungen.
- 18) Dieses Gerät kann von Kindern ab 8 Jahren und Personen verwendet werden mit eingeschränkten physischen, sensorischen oder geistigen Fähigkeiten oder mangelnder Erfahrung und wenn sie beabsichtigt werden oder Anweisungen zur Benutzung des Geräts erhalten haben. Gerät sicher bedienen und die damit verbundenen Gefahren verstehen. Kinder dürfen nicht mit dem Gerät spielen.

das Gerät. Reinigung und Benutzerwartung dürfen nicht von Kindern ohne Aufsicht.

2. Typ Y-Anschluss: Wenn das Netzkabel beschädigt ist, muss es durch den

Um eine Gefährdung zu vermeiden, müssen Sie sich an den Hersteller, seinen Kundendienst oder ähnlich qualifizierte Personen wenden.


3. Um eine Gefährdung durch unbeabsichtigtes Zurücksetzen des Thermoschutzschalters zu vermeiden,

Das Gerät darf nicht über ein externes Schaltgerät, wie z. B. eine Zeitschaltuhr, mit Strom versorgt werden, oder an einen Stromkreis angeschlossen, der vom Versorgungsunternehmen regelmäßig ein- und ausgeschaltet wird.

4. Während der Temperatureinstellung tritt eine leichte Verzögerung in der Digitalanzeige auf Temperatur, was ein normales Phänomen ist. Bitte warten Sie einen Moment.

BEWAHREN SIE DIESE ANWEISUNGEN AUF

Bedienungsanleitung für die LPyrograph-Maschine



1) Pyrograph-Maschinenschalter: Schalten Sie den Schalter ein, wenn Sie ihn verwenden, und schalten Sie ihn aus bei Nichtgebrauch, um Gefahren zu vermeiden.

2) Thermostat: Damit wird die Temperatur des Pyrographen eingestellt. Das Licht Der graue Teil ist die normale Einstellung der Rendering-Temperatur und der rote Teil ist der Hochtemperaturbereich. Die Temperaturregelung der elektrischen Heizung

Beim Drahtstift wird die Temperatur langsam über den Temperaturregler eingestellt. Wenn die Temperatur angezeigt wird, stellen Sie die Temperatur auf 700 Grad ein und senken Sie sie dann langsam ab. Am besten liegt die Temperatur bei etwa 350–600 Grad und die niedrigste Temperatur bei etwa 350–450 Grad. Stellen Sie beim Einstellen der Temperatur die Spitze des elektrischen Heizdrahtstifts von etwas gräulich-orange auf nicht rot ein. Nicht zu rot werden lassen, da eine zu hohe Temperatur den Stift weich macht und er nicht mehr normal zeichnen kann, die Leistung stark abfällt und die gezeichnete Linie verbrannt wird. 3) Pyrograph-Stiftbuchse: Der Stecker des Pyrograph-Stifts sollte eng mit der Buchse verbunden sein, der Stecker sollte in die Unterseite der Buchse eingesteckt werden, was eng verbunden sein sollte, um eine Überhitzung und ein Verbrennen des Zubehörs zu vermeiden

Thermometer: Die Temperatur der Brandmalereimaschine wird durch Anpassen des Temperaturwerts eingestellt und der Anzeigebereich der Temperatureinstellung beträgt 300–700 Grad.

Vorsichtsmaßnahmen für den Pyrographen: 1)

Ziehen Sie die Schraube der Stiftspitze fest, wenn Sie die Stiftspitze anbringen. Vermeiden Sie einen schlechten Kontakt zwischen der Stiftspitze und dem Anschluss, so dass die Stiftspitze nicht heiß wird. Eine Überhitzung des Anschlusses führt zum Durchbrennen der Zubehörteile. Wenn der Anschluss zu heiß ist, d. h. die Stiftspitze ist nicht fest befestigt, und sie sollte rechtzeitig mit einem Schraubendreher festgezogen werden.

2) Wählen Sie einen Heizdraht unter 1 mm als Stiftspitze. Wählen Sie keine anderen nicht heizenden Drahtmaterialien wie Eisendraht als Stiftspitze, da dies sehr gefährlich ist und leicht alle Zubehörteile in der Bewegung durchbrennen kann, und es ist einfach kann zu Stromschlägen und Bränden führen.


Richtige Installation der Stiftspitze eines Pyrographen

Die Stiftspitze des Pyrographen ist nicht heiß und die Temperatur ist plötzlich hoch und plötzlich niedrig. Aus der Stiftspitze kommen Funken und der Stifthalter ist heiß, wenn man ihn anfasst. Was sind die Gründe? Es liegt an der falschen Installation der Stiftspitze.




•Hier muss die obere Schraube mehr als 4 mm herausragen, und die Schraube muss herausragen dieser Abstand und wird in die Stiftspitze eingesetzt.

•Es ist falsch, die Schraube in diesem Abstand in die Stiftspitze einzusetzen.




•Die Füße der Stiftspitze müssen in die Kupfer-Anschlussklemme gesteckt werden, um mehr als 8 mm.

•Die Kupfer-Anschlussklemme mit Stiftspitze



• Ziehen Sie die Schraube mit dem Schraubendreher fest und ziehen Sie die Füße der Stiftspitze fest! Es muss fest verschlossen sein, sonst wird die Stiftspitze nicht erhitzt oder die Heizung wird anormal oder sogar Funken. • Die Schraube leckt zu viel nach außen, und es ist sicher, dass die Füße der Stiftspitze nicht angezogen, was falsch ist.



Das Wichtigste ist, die Stiftspitze richtig einzusetzen.

Es gibt einige Symptome der falschen Installation der Stiftspitze, die die anormale Hitze der Stiftspitze, instabile Temperatur der Stiftspitze, Funkenbildung von der Stiftspitze, der Erhitzung der Kupfersäule und der glühenden Hitze des Stifts Halter.

Technische Daten


Modell	LH50	
Nennspannung	120 V ~ 60 Hz für die USA	220-240 V ~ 50 Hz Für EU oder AU
Leistung	20 W	

In China hergestellt

VEVOR®
TOUGH TOOLS, HALF PRICE

Technischer Support und E-Garantie-Zertifikat
www.vevor.com/support

Instruction Manual of LH40-2 Pyrography Machine



The adjustment of the temperature of the wood burning pen is slowly adjusted by the thermostat, first of all, the temperature is adjusted to about 600 degrees and then slowly adjusted to a lower place, the best temperature is about 300-500 degrees. Low temperature rendering is best used in the range of 250-400 degrees. When rendering temperature adjustment, watching wood burning pen can burn light colors on the material, the temperature at this time is the best rendering effect (different material density and humidity need different optimal temperatures, please be patient to debug). You can draw the color painting with different shades and layers over and over again. If the temperature is too high, it is difficult to render the delicate picture effect. When tracing the line, the temperature can be appropriately increased, and smooth lines can be drawn according to your own situation. If you want to bake the line well, you should learn to slow down the pen at low temperature. The lower the temperature of the burning wood used, the slower the writing pen, the better the painting effect.

3) Thermometer: The temperature of the pyrography machine is adjusted by adjusting the Temperature value, and the temperature adjustment display range is 250-700 degrees.

4) pyrograph pen socket: Two with dual port configuration, press the button to quickly change pens. The pyrograph pen plug should be closely matched with the socket, the plug should be inserted into the bottom of the socket, which should be closely matched to avoid overheating and burning accessories.

5) Conversion switch: When using the A-point wood burning pen, press |, and the A-point wood burning pen will be powered on and immediately generate heat. When using the B-point wood burning pen, press ||, and the B-point wood burning pen will be powered on and immediately generate heat.

Note for pyrography machine:

1) Tighten the screw of the pen tip when applying the pen tip, avoid poor contact between the pen tip and the terminal so that the pen tip is not hot. The overheating of the terminal will burn out the accessories, If the terminal is too hot, that is the pen tip is not tightly fastened, and it should be fastened with a screwdriver in time.

2) Select a heating wire under 1 mm as the pen tip. Do not choose other non-heating wire materials such as iron wire as the pen tip, which is very dangerous and easy to burn out all the accessories in the movement, and it is easy to cause electric shock and fire. movement, and it is very easy to get electric shock and fire.

Instructions for using the wood burning wire tip

1) The function of the bent shape wire pen tip is introduced



No. 1 No. 5 No. 9 No. 12 No. 14 No. 16 No. 19 No. 21 No. 22 No. 23 No. 24 No. 27 No. 28 No. 30

Tips for using a bent metal wire pen tip. The main function of a bent pen tip is to trace lines and render small areas of silk hair. When tracing lines, the blue indicator on the temperature control knob points towards around 250C-350C. Slowly move the pen and do not move too fast. Look at the smooth edges of the line color, and the entire line color should be uniform and just right. When rendering, adjust the temperature to around 220C-300 °C, and draw hair fine lines at a temperature of around 250 °C -350C.

2) Pointed flat shape of metal wire pen head function introduction



No. 2 No. 7 No. 11 No. 18 No. 26

Tips for using pointed metal wire pen tips: Pointed pen tips mainly focus on drawing fine lines and rendering fine parts. The temperature for drawing fine lines is 220-250 °C, and the temperature for rendering fine parts is 220-230 °C. When rendering, it is best to watch the color change slightly on the gourd and wooden board, and gradually deepen the color so that the color is delicate and rich. Dark color rendering is best at around 300 °C.

3) Flat shape wire pen tip function introduction



No. 3 No. 4 No. 6 No. 8 No. 10 No. 13 No. 15 No. 17 No. 20 No. 25 No. 29

The flat metal wire pen head is mainly used for flat rendering and side silk line drawing. The temperature for flat rendering is around 220C-290 °C for light colors, and 300C-400 °C for dark colors.

Summary: The temperature of the pen head introduced earlier should not be too dogmatic and rigid. Depending on the density, humidity, and hardness of the material used for soldering, the temperature required for soldering may vary. You can learn from and adjust the experiment flexibly to find the most suitable temperature for yourself. Whether it's writing, tracing, or rendering, if you want good results, you would rather use the pen slowly at low temperatures to deepen layer by layer. Never use a pen quickly at high temperatures. It is difficult to see works with uneven lines, uneven rendering colors, uneven depth, rough and delicate images.

Correct installation of pen point of pyrography

The pen point of pyrograph is not hot, and the temperature is suddenly high, and suddenly low. There are sparks coming from the pen point and the penholder is hot to grasp. What are the reasons? It's because the incorrect installation of the pen point.



1
Unscrew both screws on the pen and detach them from the hole where the pen head is installed, making it easier for the pen head to be inserted smoothly to the bottom. The effect is shown in the above picture.



2
The picture above correctly shows the effect by inserting the two pins of the pen tip into the bottom of the hole inside.







3
Finally, tighten the two screws with appropriate torque, be sure to tighten.







4
Screw does not hold pen tip two pins, error! The pen tip does not heat up properly.

there are some symptoms of the incorrect installation of pen point , which are the abnormal heat of pen point , unstable temperature of pen point , sparks generating from the pen point, the heating of copper column and the burning hot of pen holder.

Tips for using wood burning pen tips



Tips for using wood burning tools and knives

<p>This is a rendering of the wood burning just now. Later, we will demonstrate the usage techniques with a carving knife.</p>  <p>1</p>	<p>Use a carving knife to scrape off unwanted images or defects. When scraping, gently scrape and try to scrape as flat and smooth as possible.</p>  <p>2</p>
<p>Techniques such as using a carving knife to scrape out highlights, fine lines, and increase the brightness of local color tones in the image</p>  <p>3</p>	<p>1) Use tweezers to clamp and adjust the angle of the pen head. The default angle of the factory made pen head is relatively small. When increasing the angle of the pen head, first set the temperature to the highest. When the pen head turns red and has good plasticity, use tweezers to clamp and bend the angle of the pen head. 2) When replacing the pen tip, it is very hot and can easily burn the skin. It is safer to replace it with tweezers.</p> 

Precautions for using a pyrography pen holder

When using a pyrography pen, the temperature of the pen tip is very high. When placing the pen in the holder, it is important to avoid the high-temperature pen tip coming into contact with the holder to avoid burning it out. When placing the pen on the holder, use the pen holder to contact and fix the pyrography brush. It is forbidden for the high-temperature pen tip to come into contact with any part of the holder.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Assistance technique et certificat de garantie électronique www.vevor.com/support

MACHINE À PYROGRAPHIER

Nous continuons à nous engager à vous fournir des outils à des prix compétitifs.

« Économisez la moitié », « Moitié prix » ou toute autre expression similaire utilisée par nous ne représente qu'une estimation des économies que vous pourriez réaliser en achetant certains outils chez nous par rapport aux grandes marques et ne couvre pas nécessairement toutes les catégories d'outils que nous proposons. Nous vous rappelons de bien vouloir vérifier soigneusement lorsque vous passez une commande chez nous si vous économisez réellement la moitié par rapport aux grandes marques.

VEVOR[®]
TOUGH TOOLS, HALF PRICE

MACHINE À PYROGRAPHIE

MODÈLE : LH50








BESOIN D'AIDE? CONTACTEZ-NOUS!

Vous avez des questions sur nos produits ? Vous avez besoin d'assistance technique ? N'hésitez pas à nous contacter :

Assistance technique et certificat de garantie
électronique www.vevor.com/support

Il s'agit de la notice d'utilisation d'origine. Veuillez lire attentivement toutes les instructions du manuel avant de l'utiliser. VEVOR se réserve le droit d'interpréter clairement notre manuel d'utilisation. L'apparence du produit dépend du produit que vous avez reçu. Veuillez nous excuser, nous ne vous informerons plus en cas de mise à jour technologique ou logicielle de notre produit.

	<p>Avertissement - Pour réduire le risque de blessure, l'utilisateur doit lire attentivement le manuel d'instructions.</p>
	<p>DÉCLARATION DE LA FCC</p> <p>Cet appareil est conforme à la partie 15 des règles de la FCC. Son fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas provoquer d'interférences nuisibles et (2) Cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.</p>
	<p>ÉLIMINATION CORRECTE</p> <p>Ce produit est soumis aux dispositions de la directive européenne 2012/19/CE. Le symbole représentant une poubelle à roulettes barrée indique que le produit doit faire l'objet d'une collecte séparée des déchets dans l'Union européenne. Cela s'applique au produit et à tous les accessoires marqués de ce symbole. Les produits marqués comme tels peuvent ne pas être jeté avec les ordures ménagères normales, mais doit être apporté dans un point de collecte pour le recyclage des appareils électriques et électroniques</p>
	<p>Ce symbole, placé avant un commentaire de sécurité, indique un type de précaution, d'avertissement ou de danger. Ignorer cet avertissement peut entraîner un accident. Veuillez toujours suivre les recommandations ci-dessous pour réduire le risque de blessure, d'incendie ou d'électrocution.</p>
	<p>Ce produit est de classe de protection II. Cela signifie qu'il est équipé isolation renforcée ou double.</p>

MESURES DE SÉCURITÉ IMPORTANTES

AVERTISSEMENT:

1. Les avertissements doivent être suivis attentivement pour éviter les blessures corporelles. Une mauvaise utilisation peut entraîner un choc électrique, un incendie, des blessures corporelles et d'autres dommages :

- 1) Gardez la machine débranchée lorsque vous la déplacez.
- 2) Gardez l'appareil débranché lors de l'installation des accessoires.
- 3) Placer sur une plate-forme plane et stable et faire fonctionner dans des conditions ventilées.
- 4) Portez un équipement de protection spécial lors de l'utilisation de la machine.
- 5) N'utilisez pas cette machine dans un endroit dangereux.
- 6) Ne l'utilisez que lorsque la machine fonctionne correctement.
- 7) Ne démontez pas et ne réparez pas cette machine.
- 8) N'utilisez pas de prise secteur non adaptée.
- 9) Ne touchez pas la plaque chauffante lorsque la machine chauffe.
- 10) Ne pas utiliser dans des environnements humides ou en contact avec de l'eau. De plus, ne infiltrer du liquide dans la machine pour éviter un incendie ou un choc électrique causé par un court-circuit circuit.

11) N'utilisez pas d'alimentation électrique qui ne correspond pas à la tension nominale.

Une alimentation qui ne correspond pas à la tension spécifiée peut provoquer un incendie ou un choc électrique.

- 12) Assurez-vous que la machine est mise à la terre afin de ne pas causer de blessures corporelles.
- 13) Ne touchez pas la tige rotative ou la partie portante avec vos doigts pendant l'utilisation cas de blessures.
- 14) Si la machine n'est pas utilisée pendant une longue période, veuillez débrancher le cordon d'alimentation de l'appareil. la prise.
- 15) N'utilisez pas la machine pendant les orages ou les éclairs pour éviter d'endommager la machine.
- 16) Placez la machine en douceur sur la table ignifuge et éloignez-la de articles inflammables et explosifs.
- 17) Veuillez cesser de l'utiliser si la machine fume, émet une odeur particulière ou devient bruyant et dans d'autres conditions anormales.
- 18) Cet appareil peut être utilisé par des enfants âgés de 8 ans et plus et des personnes ayant des capacités physiques, sensorielles ou mentales réduites ou manquant d'expérience et connaissances s'ils ont reçu une supervision ou des instructions concernant l'utilisation du Utilisez l'appareil de manière sûre et comprenez les dangers encourus. Les enfants ne doivent pas jouer avec

l'appareil. Le nettoyage et l'entretien par l'utilisateur ne doivent pas être effectués par des enfants sans surveillance.


2. Fixation de type Y : Si le cordon d'alimentation est endommagé, il doit être remplacé par le fabricant, son agent de service ou des personnes de qualification similaire afin d'éviter tout danger.

3. Afin d'éviter tout danger dû à une réinitialisation involontaire du coupe-circuit thermique, l'appareil ne doit pas être alimenté par un dispositif de commutation externe, tel qu'une minuterie, ou connecté à un circuit qui est régulièrement allumé et éteint par le service public.

4. Au cours du processus de réglage de la température, il y aura un léger retard dans l'affichage numérique température, ce qui est un phénomène normal, veuillez patienter un instant.

CONSERVEZ CES INSTRUCTIONS

Manuel d'instructions de la machine LPyrograph



1) Interrupteur de la machine pyrogravure : allumez l'interrupteur lorsque vous l'utilisez et éteignez-le lorsqu'il n'est pas utilisé pour éviter tout danger.

2) Thermostat : il est utilisé pour régler la température du stylo pyrograveur. La lumière la partie grise est le réglage normal de la température de rendu et la partie rouge est la zone à haute température. Le réglage de la température du chauffage électrique

Le stylo à fil doit régler lentement la température via le régulateur de température. S'il s'agit d'un affichage de température, réglez la température à 700 degrés, puis baissez-la lentement, il serait préférable que la température soit d'environ 350 à 600 degrés et que le rendu à basse température soit d'environ 350 à 450 degrés. Lors du réglage de la température, ajustez la pointe du stylo à fil chauffant électrique d'un peu d'orange grisâtre à pas rouge. Ne soyez pas trop rouge, une température trop élevée rendra le stylo mou et incapable de dessiner normalement, les performances chuteront brusquement et la ligne tracée sera brûlée. 3) Prise du stylo pyrographe : la prise du stylo pyrographe doit être étroitement adaptée à la prise, la prise doit être insérée dans le bas de la prise, qui doit être étroitement adaptée pour éviter la surchauffe et la combustion des accessoires

Thermomètre : La température de la machine de pyrogravure est réglée en ajustant la valeur de température et la plage d'affichage de réglage de la température est de 300 à 700 degrés.

Précautions pour la machine pyrograveuse : 1)

Serrez la vis de la pointe du stylo lors de l'application de la pointe du stylo, évitez un mauvais contact entre la pointe du stylo et le terminal afin que la pointe du stylo ne soit pas chaude. La surchauffe du terminal brûlera les accessoires. Si le terminal est trop chaud, c'est que la pointe du stylo n'est pas bien fixée et elle doit être fixée avec un tournevis à temps.

2) Sélectionnez un fil chauffant de moins de 1 mm comme pointe du stylo. Ne choisissez pas d'autres matériaux de fil non chauffants tels que le fil de fer comme pointe du stylo, ce qui est très dangereux et facile à brûler tous les accessoires du mouvement, et c'est facile provoquer un choc électrique et un incendie.


Installation correcte de la pointe du stylo pyrograveur

La pointe du stylo pyrograveur n'est pas chaude et la température monte et descend soudainement. Des étincelles sortent de la pointe du stylo et le porte-stylo est chaud à saisir. Quelles en sont les raisons ? C'est dû à une mauvaise installation de la pointe du stylo.




Ici, la vis supérieure doit sortir de plus de 4 mm et la vis doit sortir cette distance et s'insère dans la pointe du stylo.

Il est incorrect d'insérer la vis dans la pointe du stylo à cette distance.




Les pieds de la pointe du stylo doivent être insérés dans la borne de liaison en cuivre pour plus de 8 mm.

La borne de reliure en cuivre de la pointe du stylo



Serrez la vis avec le tournevis et serrez les pieds de la pointe du stylo !
doit être bien fermé ; sinon, la pointe du stylo ne sera pas chauffée ou son chauffage sera
anormal voire des étincelles.

La vis fuit trop à l'extérieur , et il est sûr que les pieds de la pointe du stylo ne sont pas
resserré ce qui est faux.



Il est essentiel d'installer correctement la pointe du stylo.

il existe certains symptômes d'une installation incorrecte de la pointe du stylo, qui sont les chaleur anormale de la pointe du stylo, température instable de la pointe du stylo, génération d'étincelles de la pointe du stylo, du chauffage de la colonne de cuivre et de la chaleur brûlante du stylo titulaire.

Données techniques


Modèle	LH50	
Tension nominale	120 V ~ 60 Hz pour les États-Unis	220-240V~ 50Hz pour l'UE ou l'AU
Puissance ¹	20 W	

Fabriqué en Chine

VEVOR[®]
TOUGH TOOLS, HALF PRICE

Assistance technique et certificat de garantie
électronique www.vevor.com/support

Instruction Manual of LH40-2 Pyrography Machine



The adjustment of the temperature of the wood burning pen is slowly adjusted by the thermostat, first of all, the temperature is adjusted to about 600 degrees and then slowly adjusted to a lower place, the best temperature is about 300-500 degrees. Low temperature rendering is best used in the range of 250-400 degrees. When rendering temperature adjustment, watching wood burning pen can burn light colors on the material, the temperature at this time is the best rendering effect (different material density and humidity need different optimal temperatures, please be patient to debug). You can draw the color painting with different shades and layers over and over again. If the temperature is too high, it is difficult to render the delicate picture effect. When tracing the line, the temperature can be appropriately increased, and smooth lines can be drawn according to your own situation. If you want to bake the line well, you should learn to slow down the pen at low temperature. The lower the temperature of the burning wood used, the slower the writing pen, the better the painting effect.

3) Thermometer: The temperature of the pyrography machine is adjusted by adjusting the Temperature value, and the temperature adjustment display range is 250-700 degrees.

4) pyrograph pen socket: Two with dual port configuration, press the button to quickly change pens. The pyrograph pen plug should be closely matched with the socket, the plug should be inserted into the bottom of the socket, which should be closely matched to avoid overheating and burning accessories.

5) Conversion switch: When using the A-point wood burning pen, press |, and the A-point wood burning pen will be powered on and immediately generate heat. When using the B-point wood burning pen, press ||, and the B-point wood burning pen will be powered on and immediately generate heat.

Note for pyrography machine:

1) Tighten the screw of the pen tip when applying the pen tip, avoid poor contact between the pen tip and the terminal so that the pen tip is not hot. The overheating of the terminal will burn out the accessories, If the terminal is too hot, that is the pen tip is not tightly fastened, and it should be fastened with a screwdriver in time.

2) Select a heating wire under 1 mm as the pen tip. Do not choose other non-heating wire materials such as iron wire as the pen tip, which is very dangerous and easy to burn out all the accessories in the movement, and it is easy to cause electric shock and fire. movement, and it is very easy to get electric shock and fire.

Instructions for using the wood burning wire tip

1) The function of the bent shape wire pen tip is introduced



No. 1 No. 5 No. 9 No. 12 No. 14 No. 16 No. 19 No. 21 No. 22 No. 23 No. 24 No. 27 No. 28 No. 30

Tips for using a bent metal wire pen tip. The main function of a bent pen tip is to trace lines and render small areas of silk hair. When tracing lines, the blue indicator on the temperature control knob points towards around 250C-350C. Slowly move the pen and do not move too fast. Look at the smooth edges of the line color, and the entire line color should be uniform and just right. When rendering, adjust the temperature to around 220C-300 °C, and draw hair fine lines at a temperature of around 250 °C -350C.

2) Pointed flat shape of metal wire pen head function introduction



No. 2 No. 7 No. 11 No. 18 No. 26

Tips for using pointed metal wire pen tips: Pointed pen tips mainly focus on drawing fine lines and rendering fine parts. The temperature for drawing fine lines is 220-250 °C, and the temperature for rendering fine parts is 220-230 °C. When rendering, it is best to watch the color change slightly on the gourd and wooden board, and gradually deepen the color so that the color is delicate and rich. Dark color rendering is best at around 300 °C.

3) Flat shape wire pen tip function introduction



No. 3 No. 4 No. 6 No. 8 No. 10 No. 13 No. 15 No. 17 No. 20 No. 25 No. 29

The flat metal wire pen head is mainly used for flat rendering and side silk line drawing. The temperature for flat rendering is around 220C-290 °C for light colors, and 300C-400 °C for dark colors.

Summary: The temperature of the pen head introduced earlier should not be too dogmatic and rigid. Depending on the density, humidity, and hardness of the material used for soldering, the temperature required for soldering may vary. You can learn from and adjust the experiment flexibly to find the most suitable temperature for yourself. Whether it's writing, tracing, or rendering, if you want good results, you would rather use the pen slowly at low temperatures to deepen layer by layer. Never use a pen quickly at high temperatures. It is difficult to see works with uneven lines, uneven rendering colors, uneven depth, rough and delicate images.

Correct installation of pen point of pyrography

The pen point of pyrograph is not hot, and the temperature is suddenly high, and suddenly low. There are sparks coming from the pen point and the penholder is hot to grasp. What are the reasons? It's because the incorrect installation of the pen point.



1
Unscrew both screws on the pen and detach them from the hole where the pen head is installed, making it easier for the pen head to be inserted smoothly to the bottom. The effect is shown in the above picture.



2
The picture above correctly shows the effect by inserting the two pins of the pen tip into the bottom of the hole inside.







3
Finally, tighten the two screws with appropriate torque, be sure to tighten.



4
Screw does not hold pen tip two pins, error! The pen tip does not heat up properly.

there are some symptoms of the incorrect installation of pen point , which are the abnormal heat of pen point , unstable temperature of pen point , sparks generating from the pen point, the heating of copper column and the burning hot of pen holder.

Tips for using wood burning pen tips



Tips for using wood burning tools and knives

This is a rendering of the wood burning just now. Later, we will demonstrate the usage techniques with a carving knife.




Use a carving knife to scrape off unwanted images or defects. When scraping, gently scrape and try to scrape as flat and smooth as possible.



Techniques such as using a carving knife to scrape out highlights, fine lines, and increase the brightness of local color tones in the image



1) Use tweezers to clamp and adjust the angle of the pen head. The default angle of the factory made pen head is relatively small. When increasing the angle of the pen head, first set the temperature to the highest. When the pen head turns red and has good plasticity, use tweezers to clamp and bend the angle of the pen head.
2) When replacing the pen tip, it is very hot and can easily burn the skin. It is safer to replace it with tweezers.



Precautions for using a pyrography pen holder

When using a pyrography pen, the temperature of the pen tip is very high. When placing the pen in the holder, it is important to avoid the high-temperature pen tip coming into contact with the holder to avoid burning it out. When placing the pen on the holder, use the pen holder to contact and fix the pyrography brush. It is forbidden for the high-temperature pen tip to come into contact with any part of the holder.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technische ondersteuning en e-garantiecertificaat www.vevor.com/support

PYROGRAAFMACHINE

Wij streven er voortdurend naar om u gereedschappen tegen concurrerende prijzen te leveren.

"Bespaar de helft", "halve prijs" of andere soortgelijke uitdrukkingen die wij gebruiken, geven alleen een schatting van de besparingen die u kunt behalen door bepaalde gereedschappen bij ons te kopen in vergelijking met de grote topmerken en doseringen betekenen niet noodzakelijkerwijs dat ze alle categorieën gereedschappen dekken die wij aanbieden. Wij herinneren u eraan om zorgvuldig te controleren of u daadwerkelijk de helft bespaart in vergelijking met de grote topmerken wanneer u een bestelling bij ons plaatst.

VEVOR[®]
TOUGH TOOLS, HALF PRICE

PYROGRAAFMACHINE

MODEL:LH50








HULP NODIG? NEEM CONTACT MET ONS OP!

Heeft u vragen over het product? Heeft u technische ondersteuning nodig? Neem dan gerust contact met ons op:

**Technische ondersteuning en e-
garantiecertificaat www.vevor.com/support**

Dit is de originele instructie, lees alle handleidingen zorgvuldig door voordat u het product gebruikt. VEVOR behoudt zich een duidelijke interpretatie van onze gebruikershandleiding voor. Het uiterlijk van het product is afhankelijk van het product dat u hebt ontvangen. Vergeef ons dat we u niet opnieuw zullen informeren als er technologie- of software-updates voor ons product zijn.

	<p>Waarschuwing: om het risico op letsel te verkleinen, moet de gebruiker de gebruiksaanwijzing zorgvuldig lezen.</p>
	<p>FCC-VERKLARING</p> <p>Dit apparaat voldoet aan Deel 15 van de FCC-regels. De werking is onderworpen aan de volgende twee voorwaarden: (1) Dit apparaat mag geen schadelijke interferentie veroorzaken, en (2) dit apparaat moet alle ontvangen interferentie accepteren, inclusief interferentie die ongewenste werking kan veroorzaken.</p>
	<p>CORRECTE VERWIJDERING</p> <p>Dit product is onderworpen aan de bepalingen van de Europese richtlijn 2012/19/EG. Het symbool met een doorgestreepte afvalbak geeft aan dat het product gescheiden afvalinzameling vereist in de Europese Unie. Dit geldt voor het product en alle accessoires die met dit symbool zijn gemarkeerd. Producten die als zodanig zijn gemarkeerd, mogen niet worden weggegooid met het normale huisvuil, maar moet naar een afvalverwerkingsbedrijf worden gebracht. Inzamelingspunt voor recycling van elektrische en elektronische apparaten</p>
	<p>Dit symbool, geplaatst voor een veiligheidsopmerking, geeft een soort voorzorgsmaatregel, waarschuwing of gevaar aan. Het negeren van deze waarschuwing kan leiden tot een ongeluk. Volg altijd de onderstaande aanbeveling om het risico op letsel, brand of elektrocutie te verminderen.</p>
	<p>Dit product is van beschermingsklasse II. Dat wil zeggen dat het is uitgerust met verbeterde of dubbele isolatie.</p>

BELANGRIJKE VEILIGHEIDSMATREGELEN

WAARSCHUWING:

1. Waarschuwingen moeten zorgvuldig worden opgevolgd om lichamelijk letsel te voorkomen. Onjuist gebruik kan resulteren in een elektrische schok, brand, persoonlijk letsel en andere schade:

1) Zorg ervoor dat de stekker uit het stopcontact is wanneer u het apparaat verplaatst.

2) Zorg ervoor dat de stekker uit het stopcontact is wanneer u accessoires installeert.

3) Plaats het op een vlak en stabiel platform en laat het werken onder geventileerde omstandigheden.

4) Draag speciale beschermende uitrusting wanneer u de machine bedient.

5) Gebruik deze machine niet op een gevaarlijke locatie.

6) Gebruik het alleen als de machine correct werkt.

7) Demonteer en repareer dit apparaat niet.

8) Gebruik geen ongeschikt stopcontact.

9) Raak de verwarmingsplaat niet aan terwijl het apparaat aan het opwarmen is.

10) Niet gebruiken in vochtige omgevingen of in contact met water. Ook niet vloeistof in de machine laten infiltreren om brand of elektrische schokken door kortsluiting te voorkomen circuit.

11) Gebruik geen voeding die niet voldoet aan de nominale spanning. De voeding

Voeding die niet aan de opgegeven spanning voldoet, kan brand of een elektrische schok veroorzaken.

12) Zorg ervoor dat het apparaat geaard is, zodat er geen lichamelijk letsel kan ontstaan.

13) Raak de draaiende stang of het lagergedeelte niet aan met uw vingers tijdens gebruik.

geval van verwondingen.

14) Als het apparaat gedurende langere tijd niet wordt gebruikt, trek dan de stekker uit het stopcontact. het stopcontact.

15) Gebruik de machine niet tijdens onweer of bliksem om schade aan de machine te voorkomen. de machine.

16) Plaats de machine op een vlakke ondergrond op de vlamvertragende tafel en houd deze uit de buurt van ontvlambare en explosieve voorwerpen.

17) Stop met het gebruik ervan als het apparaat rookt, een vreemde geur afgeeft of lawaaierig en onder andere abnormale omstandigheden.

18) Dit apparaat kan worden gebruikt door kinderen van 8 jaar en ouder en door personen

met verminderde fysieke, sensorische of mentale vermogens of gebrek aan ervaring en

kennis als zij toezicht of instructie hebben gekregen met betrekking tot het gebruik van de

apparaat op een veilige manier gebruiken en de gevaren begrijpen die ermee gepaard gaan. Kinderen mogen niet met het apparaat spelen

het apparaat. Reiniging en gebruikersonderhoud mogen niet door kinderen worden uitgevoerd zonder overzicht.

2. Type Y-aansluiting: Als het netsnoer beschadigd is, moet het door de fabrikant worden vervangen.

de fabrikant, diens serviceagent of personen met vergelijkbare kwalificaties om gevaar te voorkomen.


3. Om gevaar te voorkomen als gevolg van onbedoelde reset van de thermische beveiliging, moet dit

Het apparaat mag niet via een extern schakelapparaat, zoals een timer, van stroom worden voorzien of aangesloten op een circuit dat regelmatig door het nutsbedrijf wordt in- en uitgeschakeld.

4. Tijdens het proces van temperatuuraanpassing zal er een kleine vertraging optreden in de digitale weergave temperatuur, wat een normaal verschijnsel is. Wacht even.

BEWAAR DEZE INSTRUCTIES

Gebruiksaanwijzing van de LPyrograph-machine



1) Schakelaar van de pyrograafmachine: Zet de schakelaar aan wanneer u hem gebruikt, en zet hem uit wanneer niet in gebruik, om gevaar te voorkomen.

2) Thermostaat: Deze wordt gebruikt om de temperatuur van de pyrograafpen aan te passen. Het licht

Het grijze gedeelte is de normale aanpassing van de renderingtemperatuur, en het rode gedeelte

is het hoge temperatuurgebied. De temperatuurregeling van de elektrische verwarming

draadpen is om de temperatuur langzaam aan te passen via de temperatuurregelaar. Als het temperatuurweergave is, pas de temperatuur dan aan tot 700 graden en verlaag deze vervolgens langzaam, het zou het beste zijn als de temperatuur rond de 350-600 graden is en de lage temperatuurweergave ongeveer 350-450 graden is. Pas bij het aanpassen van de temperatuur de punt van de elektrische verwarmingsdraadpen aan van een beetje grijsachtig oranje naar niet rood. Wees niet te rood, te hoge temperaturen maken de pen zacht en kunnen niet normaal tekenen, de prestaties zullen sterk dalen en de getekende lijn zal verbranden. 3) pyrograafpen-aansluiting: De pyrograafpen-stekker moet nauw aansluiten op de aansluiting, de stekker moet in de onderkant van de aansluiting worden gestoken, die nauw moet aansluiten om oververhitting en verbranding van accessoires te voorkomen


Thermometer: De temperatuur van de pyrografiemachine wordt aangepast door de temperatuurwaarde aan te passen. Het weergavebereik van de temperatuurinstelling ligt tussen 300 en 700 graden.

Voorzorgsmaatregelen voor pyrograafmachines:


- 1) Draai de schroef van de penpunt vast wanneer u de penpunt aanbrengt. Vermijd slecht contact tussen de penpunt en de aansluiting, zodat de penpunt niet heet wordt. Oververhitting van de aansluiting kan de accessoires doen doorbranden. Als de aansluiting te heet is, betekent dit dat de penpunt niet goed vastzit. In dat geval moet u deze op tijd vastzetten met een schroevendraaier.
- 2) Selecteer een verwarmingsdraad van minder dan 1 mm als de punt van de pen. Kies geen andere niet-verwarmende draadmaterialen zoals ijzerdraad als de punt van de pen, wat erg gevaarlijk is en gemakkelijk alle accessoires in het uurwerk kan doen doorbranden, en het is gemakkelijk elektrische schokken en brand veroorzaken.

Correcte installatie van de penpunt van de pyrograaf

De penpunt van de pyrograaf is niet heet, en de temperatuur is plotseling hoog, en plotseling laag. Er komen vonken uit de penpunt en de penhouder is heet om vast te pakken. Wat zijn de redenen? Het komt door de onjuiste installatie van de penpunt.




• Hier moet de bovenste schroef meer dan 4 mm uitsteken en de schroef moet op deze afstand en wordt in de punt van de pen gestoken. • Het is verkeerd om de schroef op deze afstand in de punt van de pen te steken.




• De voetjes van de penpunt moeten in de koperen aansluitpaal worden gestoken voor meer dan 8 mm.

• De koperen bindingspaal met penpunt



• Draai de schroef vast met de schroevendraaier en draai de voetjes van de penpunt vast!
moet goed gesloten zijn; anders wordt de punt van de pen niet verwarmd of wordt de verwarming ervan
abnormaal of zelfs vonken. • De
schroef lekt te veel naar buiten , en het is zeker dat de voeten van de penpunt niet
aangescherpt, wat fout is.



Het is essentieel dat de penpunt correct wordt geïnstalleerd.

Er zijn enkele symptomen van een onjuiste installatie van de penpunt, namelijk:

abnormale hitte van de penpunt, onstabiele temperatuur van de penpunt, vonken die ontstaan van de penpunt, de verhitting van de koperen kolom en de brandende hitte van de pen houder.

Technische gegevens


Model	LH50	
Nominale spanning	120V~ 60Hz voor de VS	220-240V~ 50Hz Voor EU of AU
Kracht P	20W	

Gemaakt in China

VEVOR[®]
TOUGH TOOLS, HALF PRICE

Technische ondersteuning en e-
garantiecertificaat www.vevor.com/support

Instruction Manual of LH40-2 Pyrography Machine



The adjustment of the temperature of the wood burning pen is slowly adjusted by the thermostat, first of all, the temperature is adjusted to about 600 degrees and then slowly adjusted to a lower place, the best temperature is about 300-500 degrees. Low temperature rendering is best used in the range of 250-400 degrees. When rendering temperature adjustment, watching wood burning pen can burn light colors on the material, the temperature at this time is the best rendering effect (different material density and humidity need different optimal temperatures, please be patient to debug). You can draw the color painting with different shades and layers over and over again. If the temperature is too high, it is difficult to render the delicate picture effect. When tracing the line, the temperature can be appropriately increased, and smooth lines can be drawn according to your own situation. If you want to bake the line well, you should learn to slow down the pen at low temperature. The lower the temperature of the burning wood used, the slower the writing pen, the better the painting effect.

3) Thermometer: The temperature of the pyrography machine is adjusted by adjusting the Temperature value, and the temperature adjustment display range is 250-700 degrees.

4) pyrograph pen socket: Two with dual port configuration, press the button to quickly change pens. The pyrograph pen plug should be closely matched with the socket, the plug should be inserted into the bottom of the socket, which should be closely matched to avoid overheating and burning accessories.

5) Conversion switch: When using the A-point wood burning pen, press |, and the A-point wood burning pen will be powered on and immediately generate heat. When using the B-point wood burning pen, press ||, and the B-point wood burning pen will be powered on and immediately generate heat.


Note for pyrography machine:

1) Tighten the screw of the pen tip when applying the pen tip, avoid poor contact between the pen tip and the terminal so that the pen tip is not hot. The overheating of the terminal will burn out the accessories, If the terminal is too hot, that is the pen tip is not tightly fastened, and it should be fastened with a screwdriver in time.

2) Select a heating wire under 1 mm as the pen tip. Do not choose other non-heating wire materials such as iron wire as the pen tip, which is very dangerous and easy to burn out all the accessories in the movement, and it is easy to cause electric shock and fire. movement, and it is very easy to get electric shock and fire.

Instructions for using the wood burning wire tip

1) The function of the bent shape wire pen tip is introduced



No. 1 No. 5 No. 9 No. 12 No. 14 No. 16 No. 19 No. 21 No. 22 No. 23 No. 24 No. 27 No. 28 No. 30

Tips for using a bent metal wire pen tip. The main function of a bent pen tip is to trace lines and render small areas of silk hair. When tracing lines, the blue indicator on the temperature control knob points towards around 250C-350C. Slowly move the pen and do not move too fast. Look at the smooth edges of the line color, and the entire line color should be uniform and just right. When rendering, adjust the temperature to around 220C-300 °C, and draw hair fine lines at a temperature of around 250 °C -350C.

2) Pointed flat shape of metal wire pen head function introduction



No. 2 No. 7 No. 11 No. 18 No. 26

Tips for using pointed metal wire pen tips: Pointed pen tips mainly focus on drawing fine lines and rendering fine parts. The temperature for drawing fine lines is 220-250 °C, and the temperature for rendering fine parts is 220-230 °C. When rendering, it is best to watch the color change slightly on the gourd and wooden board, and gradually deepen the color so that the color is delicate and rich. Dark color rendering is best at around 300 °C.

3) Flat shape wire pen tip function introduction



No. 3 No. 4 No. 6 No. 8 No. 10 No. 13 No. 15 No. 17 No. 20 No. 25 No. 29

The flat metal wire pen head is mainly used for flat rendering and side silk line drawing. The temperature for flat rendering is around 220C-290 °C for light colors, and 300C-400 °C for dark colors.

Summary: The temperature of the pen head introduced earlier should not be too dogmatic and rigid. Depending on the density, humidity, and hardness of the material used for soldering, the temperature required for soldering may vary. You can learn from and adjust the experiment flexibly to find the most suitable temperature for yourself. Whether it's writing, tracing, or rendering, if you want good results, you would rather use the pen slowly at low temperatures to deepen layer by layer. Never use a pen quickly at high temperatures. It is difficult to see works with uneven lines, uneven rendering colors, uneven depth, rough and delicate images.

Correct installation of pen point of pyrography

The pen point of pyrograph is not hot, and the temperature is suddenly high, and suddenly low. There are sparks coming from the pen point and the penholder is hot to grasp. What are the reasons? It's because the incorrect installation of the pen point.



1
Unscrew both screws on the pen and detach them from the hole where the pen head is installed, making it easier for the pen head to be inserted smoothly to the bottom. The effect is shown in the above picture.



2
The picture above correctly shows the effect by inserting the two pins of the pen tip into the bottom of the hole inside.







3
Finally, tighten the two screws with appropriate torque, be sure to tighten.



4
Screw does not hold pen tip two pins, error! The pen tip does not heat up properly.

there are some symptoms of the incorrect installation of pen point , which are the abnormal heat of pen point , unstable temperature of pen point , sparks generating from the pen point, the heating of copper column and the burning hot of pen holder.

Tips for using wood burning pen tips



Tips for using wood burning tools and knives

This is a rendering of the wood burning just now. Later, we will demonstrate the usage techniques with a carving knife.




Use a carving knife to scrape off unwanted images or defects. When scraping, gently scrape and try to scrape as flat and smooth as possible.



Techniques such as using a carving knife to scrape out highlights, fine lines, and increase the brightness of local color tones in the image



1) Use tweezers to clamp and adjust the angle of the pen head. The default angle of the factory made pen head is relatively small. When increasing the angle of the pen head, first set the temperature to the highest. When the pen head turns red and has good plasticity, use tweezers to clamp and bend the angle of the pen head.
2) When replacing the pen tip, it is very hot and can easily burn the skin. It is safer to replace it with tweezers.



Precautions for using a pyrography pen holder

When using a pyrography pen, the temperature of the pen tip is very high. When placing the pen in the holder, it is important to avoid the high-temperature pen tip coming into contact with the holder to avoid burning it out. When placing the pen on the holder, use the pen holder to contact and fix the pyrography brush. It is forbidden for the high-temperature pen tip to come into contact with any part of the holder.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Teknisk support och e-garanticertifikat www.vevor.com/support

PYROGRAFMASKIN

Vi fortsätter att vara engagerade i att ge dig verktyg till konkurrenskraftiga priser.

"Spara halva", "halva priset" eller andra liknande uttryck som används av oss representerar bara en uppskattning av besparingar du kan dra nytta av att köpa vissa verktyg hos oss jämfört med de stora toppmärkena och doser behöver inte nödvändigtvis täcka alla kategorier av verktyg som erbjuds av oss. Du påminns vänligen om att noggrant kontrollera när du gör en beställning hos oss om du faktiskt sparar hälften i jämförelse med de främsta stora varumärkena.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

PYROGRAFMASKIN

MODELL: LH50








BEHÖVER HJÄLP? KONTAKTA OSS!

Har du produktfrågor? Behöver du teknisk support? Kontakta oss gärna:

Teknisk support och e-garanticertifikat
www.vevor.com/support

Detta är den ursprungliga instruktionen, läs alla instruktioner noggrant innan du använder den. VEVOR reserverar sig för en tydlig tolkning av vår användarmanual. Utseendet på produkten är beroende av den produkt du fått. Ursäkta oss att vi inte kommer att informera dig igen om det finns någon teknik eller mjukvaruuppdateringar på vår produkt.

	<p>Varning - För att minska risken för skada måste användaren läsa instruktionerna noggrant.</p>
	<p>FCC-UTTALANDE</p> <p>Denna enhet uppfyller del 15 av FCC-reglerna. Driften är föremål för följande två villkor: (1) Den här enheten får inte orsaka skadliga störningar och (2) den här enheten måste acceptera alla mottagna störningar, inklusive störningar som kan orsaka oönskad funktion.</p>
	<p>KORREKT AVFALLSHANTERING</p> <p>Denna produkt omfattas av bestämmelserna i det europeiska direktivet 2012/19/EC. Symbolen som visar en soptunna korsad anger att produkten kräver separat sophämtning i EU. Detta gäller för produkten och alla tillbehör märkta med denna symbol. Produkter märkta som sådana kanske inte är det</p> <p>kasseras med vanligt hushållsavfall, men måste tas till en insamlingsställe för återvinning av elektriska och elektroniska apparater</p>
	<p>Denna symbol, placerad före en säkerhetskommentar, indikerar en slags försiktighetsåtgärd, varning eller fara. Att ignorera denna varning kan leda till en olycka. Följ alltid rekommendationen nedan för att minska risken för skada, brand eller elstöt.</p>
	<p>Denna produkt är av skyddsklass II. Det betyder att den är utrustad med förstärkt eller dubbel isolering.</p>

VIKTIGA SÄKERHETSÅTGÄRDER

VARNING:

1. Varningar måste följas noggrant för att undvika kroppsskador. felaktig användning kan resultera i elektriska stötar, brand, personskador och andra skador:

1) Se till att vara urkopplad när du flyttar maskinen.

2) Se till att vara urkopplad när du installerar tillbehör.

3) Placera på en plan och stabil plattform och kör under ventilerade förhållanden.

4) Bär speciell skyddsutrustning när du använder maskinen.

5) Använd inte denna maskin på en farlig plats.

6) Använd den endast när maskinen fungerar korrekt.

7) Ta inte isär och reparera denna maskin.

8) Använd inte ett olämpligt vägguttag.

9) Rör inte vid värmeplattan när maskinen värms upp.

10) Använd inte i fuktiga miljöer eller i kontakt med vatten. Inte heller

infiltrera vätska i maskinen för att förhindra brand eller elektriska stötar orsakade av kortslutning krets.

11) Använd inte en strömkälla som inte uppfyller märkspänningen. Kraften

strömförsörjning som inte uppfyller den specificerade spänningen kan orsaka brand eller elektriska stötar.

12) Se till att maskinen är jordad för att inte skada kroppen.

13) Rör inte den roterande stången eller lagerdelen med fingrarna under användning i fall av skador.

14) Om maskinen inte används under en längre tid, vänligen koppla ur nätsladden från uttaget.

15) Använd inte maskinen under åskväder eller belysning för att undvika skador på maskinen.

16) Placera maskinen smidigt på det flamskyddade bordet och håll undan brandfarliga och explosiva föremål.

17) Sluta använda den om maskinen ryker, avger en märklig lukt eller blir bullriga och under andra onormala förhållanden.

18) Denna apparat kan användas av barn från 8 år och uppåt och personer

med nedsatt fysisk, sensorisk eller mental förmåga eller brist på erfarenhet och

kunskap om de har fått handledning eller instruktioner om användningen av

apparaten på ett säkert sätt och förstå de risker som är involverade. Barn ska inte leka med

apparaten. Rengöring och användarunderhåll får inte utföras av barn utan tillsyn.


2. Typ Y-tillbehör: Om nätsladden är skadad måste den bytas ut mot tillverkaren, dess serviceombud eller liknande kvalificerade personer för att undvika fara.

3. För att undvika en fara på grund av oavsiktlig återställning av termoskyddet, apparaten får inte försörjas via en extern omkopplingsanordning, såsom en timer, eller ansluten till en krets som regelbundet slås på och av av kraftverket.

4. Under temperaturjusteringsprocessen kommer det att finnas en liten fördröjning i den digitala displayen temperatur, vilket är ett normalt fenomen, vänta ett ögonblick.

SPARA DESSA INSTRUKTIONER

Instruktionsmanual för LPyrograph Machine



1) Brytare för pyrografmaskin: Slå på strömbrytaren när du använder den och stäng av den när den inte används för att undvika fara.

2) Termostat: Den används för att justera temperaturen på pyrografpennan. Ljuset grå del är den normala justeringen av återgivningstemperaturen och den röda delen är området med hög temperatur. Temperaturjusteringen av elvärmen

tråd penna är att långsamt justera temperaturen genom temperaturregulatorn. Om det är temperaturvisning, justera temperaturen till 700 grader och sänk den sedan långsamt, det är bäst att temperaturen är runt 350-600 grader och den låga temperaturåtergivningen är ungefär 350-450 grader. När du justerar temperaturen, justera spetsen av den elektriska värmetrådspennan från lite gråorange till inte röd. Var inte för röd, för hög temperatur kommer att göra pennan mjuk och oförmögen att rita normalt kommer prestandan att sjunka kraftigt och linjen som dras kommer att brännas. 3) pyrografpennans uttag: Pyrografpennans stickpropp ska vara nära matchad med uttaget, kontakten ska sättas in i botten av uttaget, som bör vara nära matchad för att undvika överhettning och brinnande tillbehör

Termometer: Temperaturen på pyrografmaskinen justeras genom att justera temperaturvärdet, och temperaturjusteringsvisningsområdet är 300-700 grader.


Försiktighetsåtgärder för pyrografmaskin: 1)

Dra åt skruven på pennspetsen när du applicerar pennspetsen, undvik dålig kontakt mellan pennspetsen och terminalen så att pennspetsen inte är varm. Överhettning av terminalen kommer att bränna ut tillbehören, Om terminalen är för varm, det vill säga att pennspetsen inte är ordentligt fastsatt, och den bör fästas med en skruvmejsel i tid.

2) Välj en värmetråd under 1 mm som pennspets. Välj inte andra icke-värmande trådmaterial som järntråd som pennspets, vilket är mycket farligt och lätt att bränna ut alla tillbehör i rörelsen, och det är lätt orsaka elektriska stötar och brand.


Korrekt installation av pyrografens penna

Pyrografens penna är inte varm och temperaturen är plötsligt hög och plötsligt låg. Det kommer gnistor från pennspetsen och pennhållaren är varm att greppa. Vilka är orsakerna? Det beror på den felaktiga installationen av pennan.




• Här måste den övre skruven gå ut mer än 4 mm, och skruven måste ut detta avstånd och sättas in i pennspetsen.

• Det är fel att skruven sätts in i pennspetsen på detta avstånd.




• Fötterna på pennspetsen ska sättas in i kopparbindningsstolpen för mer än 8 mm.

• Pennpunkten för kopparbindning



• Dra åt skruven med skruvmejseln och dra åt pennspetsens fötter! Det måste vara tätt stängd; annars kommer inte pennspetsen att värmas eller dess uppvärmning onormala eller till och med gnistor. • Skruven läcker för mycket utanför, och det är säkert att fötterna på pennspetsen inte är det åtdragna vilket är fel.



Det är viktigt att installera pennspetsen korrekt.

det finns några symptom på felaktig installation av penna punkt , som är onormal värme i pennspetsen, instabil temperatur på pennspetsen, gnistor genererar från pennspetsen, uppvärmningen av kopparpelaren och den brinnande heta pennan hållare.

Tekniska data


Modell	LH50	
Märkspänning	120V~ 60Hz För USA	220-240V~ 50Hz För EU eller AU
Power	20W	

Tillverkad i Kina

VEVOR®
TOUGH TOOLS, HALF PRICE

Teknisk support och e-garanticertifikat
www.vevor.com/support

Instruction Manual of LH40-2 Pyrography Machine



The adjustment of the temperature of the wood burning pen is slowly adjusted by the thermostat, first of all, the temperature is adjusted to about 600 degrees and then slowly adjusted to a lower place, the best temperature is about 300-500 degrees. Low temperature rendering is best used in the range of 250-400 degrees. When rendering temperature adjustment, watching wood burning pen can burn light colors on the material, the temperature at this time is the best rendering effect (different material density and humidity need different optimal temperatures, please be patient to debug). You can draw the color painting with different shades and layers over and over again. If the temperature is too high, it is difficult to render the delicate picture effect. When tracing the line, the temperature can be appropriately increased, and smooth lines can be drawn according to your own situation. If you want to bake the line well, you should learn to slow down the pen at low temperature. The lower the temperature of the burning wood used, the slower the writing pen, the better the painting effect.

3) Thermometer: The temperature of the pyrography machine is adjusted by adjusting the Temperature value, and the temperature adjustment display range is 250-700 degrees.

4) pyrograph pen socket: Two with dual port configuration, press the button to quickly change pens. The pyrograph pen plug should be closely matched with the socket, the plug should be inserted into the bottom of the socket, which should be closely matched to avoid overheating and burning accessories.

5) Conversion switch: When using the A-point wood burning pen, press |, and the A-point wood burning pen will be powered on and immediately generate heat. When using the B-point wood burning pen, press ||, and the B-point wood burning pen will be powered on and immediately generate heat.


Note for pyrography machine:

1) Tighten the screw of the pen tip when applying the pen tip, avoid poor contact between the pen tip and the terminal so that the pen tip is not hot. The overheating of the terminal will burn out the accessories, If the terminal is too hot, that is the pen tip is not tightly fastened, and it should be fastened with a screwdriver in time.

2) Select a heating wire under 1 mm as the pen tip. Do not choose other non-heating wire materials such as iron wire as the pen tip, which is very dangerous and easy to burn out all the accessories in the movement, and it is easy to cause electric shock and fire. movement, and it is very easy to get electric shock and fire.

Instructions for using the wood burning wire tip

1) The function of the bent shape wire pen tip is introduced



No. 1 No. 5 No. 9 No. 12 No. 14 No. 16 No. 19 No. 21 No. 22 No. 23 No. 24 No. 27 No. 28 No. 30

Tips for using a bent metal wire pen tip. The main function of a bent pen tip is to trace lines and render small areas of silk hair. When tracing lines, the blue indicator on the temperature control knob points towards around 250C-350C. Slowly move the pen and do not move too fast. Look at the smooth edges of the line color, and the entire line color should be uniform and just right. When rendering, adjust the temperature to around 220C-300 °C, and draw hair fine lines at a temperature of around 250 °C -350C.

2) Pointed flat shape of metal wire pen head function introduction



No. 2 No. 7 No. 11 No. 18 No. 26

Tips for using pointed metal wire pen tips: Pointed pen tips mainly focus on drawing fine lines and rendering fine parts. The temperature for drawing fine lines is 220-250 °C, and the temperature for rendering fine parts is 220-230 °C. When rendering, it is best to watch the color change slightly on the gourd and wooden board, and gradually deepen the color so that the color is delicate and rich. Dark color rendering is best at around 300 °C.

3) Flat shape wire pen tip function introduction



No. 3 No. 4 No. 6 No. 8 No. 10 No. 13 No. 15 No. 17 No. 20 No. 25 No. 29

The flat metal wire pen head is mainly used for flat rendering and side silk line drawing. The temperature for flat rendering is around 220C-290 °C for light colors, and 300C-400 °C for dark colors.

Summary: The temperature of the pen head introduced earlier should not be too dogmatic and rigid. Depending on the density, humidity, and hardness of the material used for soldering, the temperature required for soldering may vary. You can learn from and adjust the experiment flexibly to find the most suitable temperature for yourself. Whether it's writing, tracing, or rendering, if you want good results, you would rather use the pen slowly at low temperatures to deepen layer by layer. Never use a pen quickly at high temperatures. It is difficult to see works with uneven lines, uneven rendering colors, uneven depth, rough and delicate images.

Correct installation of pen point of pyrography

The pen point of pyrograph is not hot, and the temperature is suddenly high, and suddenly low. There are sparks coming from the pen point and the penholder is hot to grasp. What are the reasons? It's because the incorrect installation of the pen point.



1
Unscrew both screws on the pen and detach them from the hole where the pen head is installed, making it easier for the pen head to be inserted smoothly to the bottom. The effect is shown in the above picture.



2
The picture above correctly shows the effect by inserting the two pins of the pen tip into the bottom of the hole inside.







3
Finally, tighten the two screws with appropriate torque, be sure to tighten.







4
Screw does not hold pen tip two pins, error! The pen tip does not heat up properly.

there are some symptoms of the incorrect installation of pen point , which are the abnormal heat of pen point , unstable temperature of pen point , sparks generating from the pen point, the heating of copper column and the burning hot of pen holder.

Tips for using wood burning pen tips



Tips for using wood burning tools and knives

<p>This is a rendering of the wood burning just now. Later, we will demonstrate the usage techniques with a carving knife.</p>  <p>1</p>	<p>Use a carving knife to scrape off unwanted images or defects. When scraping, gently scrape and try to scrape as flat and smooth as possible.</p>  <p>2</p>
<p>Techniques such as using a carving knife to scrape out highlights, fine lines, and increase the brightness of local color tones in the image</p>  <p>3</p>	<p>1) Use tweezers to clamp and adjust the angle of the pen head. The default angle of the factory made pen head is relatively small. When increasing the angle of the pen head, first set the temperature to the highest. When the pen head turns red and has good plasticity, use tweezers to clamp and bend the angle of the pen head. 2) When replacing the pen tip, it is very hot and can easily burn the skin. It is safer to replace it with tweezers.</p> 

Precautions for using a pyrography pen holder

When using a pyrography pen, the temperature of the pen tip is very high. When placing the pen in the holder, it is important to avoid the high-temperature pen tip coming into contact with the holder to avoid burning it out. When placing the pen on the holder, use the pen holder to contact and fix the pyrography brush. It is forbidden for the high-temperature pen tip to come into contact with any part of the holder.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Soporte técnico y certificado de garantía electrónica www.vevor.com/support

MÁQUINA PIRÓGRAFA

Seguimos comprometidos a brindarle herramientas a precios competitivos.

"Ahorre la mitad", "mitad de precio" o cualquier otra expresión similar que utilicemos solo representa una estimación del ahorro que podría obtener al comprar ciertas herramientas con nosotros en comparación con las principales marcas y no necesariamente significa que cubra todas las categorías de herramientas que ofrecemos. Le recordamos que, al realizar un pedido con nosotros, verifique cuidadosamente si realmente está ahorrando la mitad en comparación con las principales marcas.

VEVOR[®]
TOUGH TOOLS, HALF PRICE

MÁQUINA PIRÓGRAFA

MODELO:LH50








¿NECESITA AYUDA? ¡CONTÁCTENOS!

¿Tiene preguntas sobre el producto? ¿Necesita asistencia técnica? No dude en ponerse en contacto con nosotros:

Soporte técnico y certificado de garantía
electrónica www.vevor.com/support

Estas son las instrucciones originales, lea atentamente todas las instrucciones del manual antes de utilizar el producto. VEVOR se reserva una interpretación clara de nuestro manual de usuario. La apariencia del producto estará sujeta al producto que recibió. Perdónenos por no informarle nuevamente si hay actualizaciones de tecnología o software en nuestro producto.

	<p>Advertencia: Para reducir el riesgo de lesiones, el usuario debe leer atentamente el manual de instrucciones.</p>
	<p>DECLARACIÓN DE LA FCC</p> <p>Este dispositivo cumple con la Parte 15 de las Normas de la FCC. Su funcionamiento está sujeto a las dos condiciones siguientes: (1) Este dispositivo no puede causar interferencias perjudiciales y (2) Este dispositivo debe aceptar cualquier interferencia que reciba, incluidas las interferencias que puedan causar un funcionamiento no deseado.</p>
	<p>ELIMINACIÓN CORRECTA</p> <p>Este producto está sujeto a las disposiciones de la Directiva Europea 2012/19/CE. El símbolo que muestra un contenedor de basura tachado indica que el producto requiere la recogida selectiva de residuos en la Unión Europea. Esto se aplica al producto y a todos los accesorios marcados con este símbolo. Los productos marcados como tales no pueden desecharse con la basura doméstica normal, sino que deben llevarse a un Punto de recogida para el reciclaje de aparatos eléctricos y electrónicos</p>
	<p>Este símbolo, colocado antes de un comentario de seguridad, indica un tipo de precaución, advertencia o peligro. Ignorar esta advertencia puede provocar un accidente. Siga siempre las recomendaciones que aparecen a continuación para reducir el riesgo de lesiones, incendios o electrocución.</p>
	<p>Este producto es de clase de protección II, es decir, está equipado con aislamiento mejorado o doble.</p>

MEDIDAS DE SEGURIDAD IMPORTANTES

ADVERTENCIA:

1. Las advertencias deben seguirse cuidadosamente para evitar lesiones corporales. El uso indebido puede provocar descargas eléctricas, incendios, lesiones personales y otros daños:

- 1) Mantener desenchufado al mover la máquina.
- 2) Mantener desenchufado al instalar accesorios.
- 3) Colóquelo sobre una plataforma plana y estable y opere en condiciones ventiladas.
- 4) Utilice equipo de protección especial al operar la máquina.
- 5) No utilice esta máquina en lugares peligrosos.
- 6) Utilícelo únicamente cuando la máquina esté funcionando correctamente.
- 7) No desmonte ni repare esta máquina.
- 8) No utilice una toma de corriente CA inadecuada.
- 9) No toque la placa calefactora cuando la máquina esté calentando.
- 10) No utilice en ambientes húmedos ni en contacto con agua. Tampoco

Infilte líquido en la máquina para evitar incendios o descargas eléctricas causadas por un cortocircuito. circuito.

- 11) No utilice una fuente de alimentación que no cumpla con el voltaje nominal.

Una fuente de alimentación que no cumpla con el voltaje especificado puede provocar un incendio o una descarga eléctrica.

- 12) Asegúrese de que la máquina esté conectada a tierra para no causar daños al cuerpo.

- 13) No toque la varilla giratoria ni la parte del cojinete con los dedos durante el uso.

caso de lesiones.

- 14) Si la máquina no se utiliza durante un largo tiempo, desconecte el cable de alimentación. el zócalo.

- 15) No utilice la máquina durante tormentas eléctricas o relámpagos para evitar daños.

La máquina.

- 16) Coloque la máquina de manera uniforme sobre la mesa ignífuga y manténgala alejada Artículos inflamables y explosivos.

- 17) Deje de utilizarla si la máquina echa humo, emite un olor peculiar o se pone ruidoso y en otras condiciones anormales.

- 18) Este aparato puede ser utilizado por niños mayores de 8 años y personas con capacidades físicas, sensoriales o mentales reducidas o falta de experiencia y conocimiento si se les ha dado supervisión o instrucción sobre el uso del aparato de forma segura y comprenda los peligros que implica. Los niños no deben jugar con él.

El aparato. La limpieza y el mantenimiento por parte del usuario no deben ser realizados por niños sin supervisión.

2. Accesorio tipo Y: Si el cable de alimentación está dañado, debe ser reemplazado por el fabricante, su agente de servicio o personas igualmente calificadas para evitar un peligro.

3. Para evitar un peligro debido a un reinicio involuntario del protector térmico, este


El aparato no debe ser alimentado a través de un dispositivo de conmutación externo, como un temporizador, o conectado a un circuito que la empresa de servicios públicos enciende y apaga periódicamente.

4. En el proceso de ajuste de temperatura, habrá un ligero retraso en la visualización digital.

temperatura, lo cual es un fenómeno normal, espere un momento.

GUARDE ESTAS INSTRUCCIONES

Manual de instrucciones de la máquina pirografo L



1) Interruptor de la máquina pirográfica: encienda el interruptor cuando la use y apáguelo cuando no esté en uso para evitar peligros.

2) Termostato: se utiliza para ajustar la temperatura del pirograbador. La luz La parte gris es el ajuste normal de la temperatura de renderizado y la parte roja es la zona de alta temperatura. El ajuste de temperatura de la calefacción eléctrica

El bolígrafo de alambre es para ajustar lentamente la temperatura a través del regulador de temperatura. Si es una pantalla de temperatura, ajuste la temperatura a 700 grados y luego bájela lentamente, lo mejor sería que la temperatura esté alrededor de 350-600 grados y la temperatura baja sea de aproximadamente 350-450 grados. Al ajustar la temperatura, ajuste la punta del bolígrafo de alambre calefactor eléctrico de un naranja ligeramente grisáceo a no rojo. No se ponga demasiado rojo, una temperatura demasiado alta hará que el bolígrafo se ablande y no pueda dibujar normalmente, el rendimiento caerá bruscamente y la línea dibujada se quemará. 3) Zócalo del bolígrafo pirograbado: El enchufe del bolígrafo pirograbado debe coincidir estrechamente con el zócalo, el enchufe debe insertarse en la parte inferior del zócalo, que debe coincidir estrechamente para evitar el sobrecalentamiento y la quema de los accesorios.

Termómetro: La temperatura de la máquina de pirografía se ajusta ajustando el valor de temperatura, y el rango de visualización del ajuste de temperatura es de 300 a 700 grados.


Precauciones para la máquina pirográfica: 1)

Apriete el tornillo de la punta del bolígrafo al aplicar la punta del bolígrafo, evite un mal contacto entre la punta del bolígrafo y el terminal para que la punta del bolígrafo no esté caliente. El sobrecalentamiento del terminal quemará los accesorios. Si el terminal está demasiado caliente, es decir, la punta del bolígrafo no está bien sujeta, y debe sujetarse con un destornillador a tiempo.

2) Seleccione un cable calefactor de menos de 1 mm como punta del bolígrafo. No elija otros materiales de cable que no sean calefactores, como el alambre de hierro, como punta del bolígrafo, que es muy peligroso y puede quemar fácilmente todos los accesorios del movimiento, y es fácil provocar descargas eléctricas e incendios.


Correcta instalación de la punta del pirografo

La punta del bolígrafo del pirograbado no está caliente y la temperatura sube y baja de repente. Salen chispas de la punta del bolígrafo y el portalápices está caliente al agarrarlo. ¿Cuáles son las razones? Se debe a la instalación incorrecta de la punta del bolígrafo.




Aquí el tornillo superior debe sobresalir más de 4 mm y el tornillo debe sobresalir. Esta distancia se inserta en la punta del bolígrafo.

No es correcto insertar el tornillo en la punta del bolígrafo a esta distancia.



Los pies de la punta del bolígrafo se insertarán en el poste de unión de cobre para mayor de 8 mm.

El poste de unión de cobre con punta de bolígrafo



¡Apriete el tornillo con el destornillador y apriete los pies de la punta del bolígrafo!


Debe estar bien cerrado; de lo contrario, la punta del bolígrafo no se calentará o su calentamiento será

El tornillo gotea

demasiado hacia afuera.

, Y es seguro que los pies de la punta del bolígrafo no están

apretado lo cual está mal.



Es esencial instalar correctamente la punta del lápiz.

Existen algunos síntomas de la instalación incorrecta de la punta del lápiz, que son los siguientes:

Calor anormal de la punta del bolígrafo, temperatura inestable de la punta del bolígrafo, generación de chispas

Desde la punta de la pluma, el calentamiento de la columna de cobre y el ardor de la pluma titular.

Datos técnicos


Modelo	LH50	
Tensión nominal	120 V ~ 60 Hz para EE. UU.	220-240 V~ 50 Hz para UE o AU
Poder a	20 W	

Hecho en china

VEVOR[®]
TOUGH TOOLS, HALF PRICE

Soporte técnico y certificado de garantía
electrónica www.vevor.com/support

Instruction Manual of LH40-2 Pyrography Machine



The adjustment of the temperature of the wood burning pen is slowly adjusted by the thermostat, first of all, the temperature is adjusted to about 600 degrees and then slowly adjusted to a lower place, the best temperature is about 300-500 degrees. Low temperature rendering is best used in the range of 250-400 degrees. When rendering temperature adjustment, watching wood burning pen can burn light colors on the material, the temperature at this time is the best rendering effect (different material density and humidity need different optimal temperatures, please be patient to debug). You can draw the color painting with different shades and layers over and over again. If the temperature is too high, it is difficult to render the delicate picture effect. When tracing the line, the temperature can be appropriately increased, and smooth lines can be drawn according to your own situation. If you want to bake the line well, you should learn to slow down the pen at low temperature. The lower the temperature of the burning wood used, the slower the writing pen, the better the painting effect.

3) Thermometer: The temperature of the pyrography machine is adjusted by adjusting the Temperature value, and the temperature adjustment display range is 250-700 degrees.

4) pyrograph pen socket: Two with dual port configuration, press the button to quickly change pens. The pyrograph pen plug should be closely matched with the socket, the plug should be inserted into the bottom of the socket, which should be closely matched to avoid overheating and burning accessories.

5) Conversion switch: When using the A-point wood burning pen, press |, and the A-point wood burning pen will be powered on and immediately generate heat. When using the B-point wood burning pen, press ||, and the B-point wood burning pen will be powered on and immediately generate heat.


Note for pyrography machine:

1) Tighten the screw of the pen tip when applying the pen tip, avoid poor contact between the pen tip and the terminal so that the pen tip is not hot. The overheating of the terminal will burn out the accessories, If the terminal is too hot, that is the pen tip is not tightly fastened, and it should be fastened with a screwdriver in time.

2) Select a heating wire under 1 mm as the pen tip. Do not choose other non-heating wire materials such as iron wire as the pen tip, which is very dangerous and easy to burn out all the accessories in the movement, and it is easy to cause electric shock and fire. movement, and it is very easy to get electric shock and fire.

Instructions for using the wood burning wire tip

1) The function of the bent shape wire pen tip is introduced



No. 1 No. 5 No. 9 No. 12 No. 14 No. 16 No. 19 No. 21 No. 22 No. 23 No. 24 No. 27 No. 28 No. 30

Tips for using a bent metal wire pen tip. The main function of a bent pen tip is to trace lines and render small areas of silk hair. When tracing lines, the blue indicator on the temperature control knob points towards around 250C-350C. Slowly move the pen and do not move too fast. Look at the smooth edges of the line color, and the entire line color should be uniform and just right. When rendering, adjust the temperature to around 220C-300 °C, and draw hair fine lines at a temperature of around 250 °C -350C.

2) Pointed flat shape of metal wire pen head function introduction



No. 2 No. 7 No. 11 No. 18 No. 26

Tips for using pointed metal wire pen tips: Pointed pen tips mainly focus on drawing fine lines and rendering fine parts. The temperature for drawing fine lines is 220-250 °C, and the temperature for rendering fine parts is 220-230 °C. When rendering, it is best to watch the color change slightly on the gourd and wooden board, and gradually deepen the color so that the color is delicate and rich. Dark color rendering is best at around 300 °C.

3) Flat shape wire pen tip function introduction



No. 3 No. 4 No. 6 No. 8 No. 10 No. 13 No. 15 No. 17 No. 20 No. 25 No. 29

The flat metal wire pen head is mainly used for flat rendering and side silk line drawing. The temperature for flat rendering is around 220C-290 °C for light colors, and 300C-400 °C for dark colors.

Summary: The temperature of the pen head introduced earlier should not be too dogmatic and rigid. Depending on the density, humidity, and hardness of the material used for soldering, the temperature required for soldering may vary. You can learn from and adjust the experiment flexibly to find the most suitable temperature for yourself. Whether it's writing, tracing, or rendering, if you want good results, you would rather use the pen slowly at low temperatures to deepen layer by layer. Never use a pen quickly at high temperatures. It is difficult to see works with uneven lines, uneven rendering colors, uneven depth, rough and delicate images.

Correct installation of pen point of pyrography

The pen point of pyrograph is not hot, and the temperature is suddenly high, and suddenly low. There are sparks coming from the pen point and the penholder is hot to grasp. What are the reasons? It's because the incorrect installation of the pen point.



1
Unscrew both screws on the pen and detach them from the hole where the pen head is installed, making it easier for the pen head to be inserted smoothly to the bottom. The effect is shown in the above picture.



2
The picture above correctly shows the effect by inserting the two pins of the pen tip into the bottom of the hole inside.







3
Finally, tighten the two screws with appropriate torque, be sure to tighten.







4
Screw does not hold pen tip two pins, error! The pen tip does not heat up properly.

there are some symptoms of the incorrect installation of pen point , which are the abnormal heat of pen point , unstable temperature of pen point , sparks generating from the pen point, the heating of copper column and the burning hot of pen holder.

Tips for using wood burning pen tips



Tips for using wood burning tools and knives

<p>This is a rendering of the wood burning just now. Later, we will demonstrate the usage techniques with a carving knife.</p>  <p>1</p>	<p>Use a carving knife to scrape off unwanted images or defects. When scraping, gently scrape and try to scrape as flat and smooth as possible.</p>  <p>2</p>
<p>Techniques such as using a carving knife to scrape out highlights, fine lines, and increase the brightness of local color tones in the image</p>  <p>3</p>	<p>1) Use tweezers to clamp and adjust the angle of the pen head. The default angle of the factory made pen head is relatively small. When increasing the angle of the pen head, first set the temperature to the highest. When the pen head turns red and has good plasticity, use tweezers to clamp and bend the angle of the pen head.</p> <p>2) When replacing the pen tip, it is very hot and can easily burn the skin. It is safer to replace it with tweezers.</p> 

Precautions for using a pyrography pen holder

When using a pyrography pen, the temperature of the pen tip is very high. When placing the pen in the holder, it is important to avoid the high-temperature pen tip coming into contact with the holder to avoid burning it out. When placing the pen on the holder, use the pen holder to contact and fix the pyrography brush. It is forbidden for the high-temperature pen tip to come into contact with any part of the holder.