

# **VEVOR<sup>®</sup>**

**TOUGH TOOLS, HALF PRICE**

Technical Support and E-Warranty Certificate [www.vevor.com/support](http://www.vevor.com/support)

## **HEAT PRESS MACHINE**

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

# VEVOR<sup>®</sup>

TOUGH TOOLS, HALF PRICE

## HEAT PRESS MACHINE

**MODEL:SS1210**



### **NEED HELP? CONTACT US!**

Have product questions? Need technical support? Please feel free to contact us:  
Technical Support and E-Warranty Certificate [www.vevor.com/support](http://www.vevor.com/support)

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

Symbol	Symbol Description
	<b>Warning:</b> To reduce the risk of injury, the user must read the instructions manual carefully.
	This symbol, placed before a safety comment, indicates a kind of precaution, warning, or danger. Ignoring this warning may lead to an accident. To reduce the risk of injury, fire, or electrocution, please always follow the recommendation shown below.
	<b>CORRECT DISPOSAL:</b> This product is subject to the provision of European Directive 2012/ 19/EC. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices.

## WARNING

1. Warnings must be followed carefully to avoid body injury, improper use may result in electric shock, fire, personal injury and other damage:

- 1) Keep unplugged when moving the machine.
- 2) Keep unplugged when installing accessories.
- 3) Place on a flat and stable platform and operate under ventilated conditions.
- 4) Wear special protective equipment when operating the machine.
- 5) Do not use this machine in a hazardous location.
- 6) Do not use when the machine is not working properly.
- 7) Do not disassemble and repair this machine.
- 8) Do not use an unsuitable AC Outlet.
- 9) Do not touch the heating plate when the machine is heating.

10) Do not use in a humid environment or contact with water. Do not infiltrate liquid in the machine to prevent fire or electric shock caused by short circuit.

11) Do not use the power supply that does not meet the rated voltage. The power supply that does not meet the specified voltage may cause fire or electric shock.

12) Ensure that the machine is grounded so as not to cause harm to body.

13) Do not touch the rotating rod or bearing part with your fingers during use in case of injuries.

14) If the machine is not in use for a long time, please unplug the power cord from the socket.

15) Do not use the machine during thunderstorms or lightning to avoid damage to the machine.

16) Place the machine smoothly on the flame-retardant table and keep away from flammable and explosive items.

17) Please stop using it if the machine smokes, emits a peculiar smell, or becomes noisy and in other abnormal conditions.

18) This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge

if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision

19) Type Y attachment: If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

20) In order to avoid a hazard due to inadvertent resetting of the thermal cutout, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

## **INTRODUCTION**

A heat press machine is using temperature and pressure with a certain amount of time to

transfer designs onto items. The transfer is permanently embedded into the product. Thank you for choosing the Heat Press Machine. Please read this user manual carefully and keep it for future reference. If you need any assistance, please email us with your Amazon order number and details.

## **FCC INFORMATION**

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment!

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This product may cause harmful interference.
- 2) This product must accept any interference received, including interference that may cause undesired operation.

**WARNING:** Changes or modifications to this product not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

**Note:** This product has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This product generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the product off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the distance between the product and receiver.
- Connect the product to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for assistance.

►SPECIFICATION



Model	SS1210	
Heat Plate Size	12x10 inch (300×260 mm)	
Voltage	120V～ 60Hz	220-240V～ 50Hz
Power	800W	770W





►Accessories list





## ► Glance Features

	<p><b>On/Off button</b></p> <p>Power on: After powering on, press the power button briefly to turn on the machine, and it will automatically heat up.</p> <p>Shutdown: Short press the power button to shut down.</p> <p>Automatic shutdown: When there is no operation within 30 minutes, the machine will automatically shut down.</p>
	<p><b>Temperature button</b></p> <p>Temperature setting: After turning on, press the temperature button briefly to enter the temperature setting, and press the +/- button to set the parameters</p> <p>Temperature unit conversion: After power on, long press the temperature button for 3 seconds to enter temperature conversion, and press the +/- button to select the temperature unit.</p>

	Time setting: After turning on, press the time key briefly to enter the time setting, and press the +/- key to set parameters.
	Set time/temperature values to increase.
	Set time/temperature values to decrease
	Countdown button

## ► Hot stamping parameters






Heat transfer ink and paper



PET Heat transfer film



## ►Operation guide

	<p>Start hot stamping</p> <ol style="list-style-type: none"><li>1. Place the T-shirt to be printed on a heat-resistant pad.</li><li>2. Place the pattern to be printed on the T-shirt and secure it with heat-resistant tape.</li></ol>
	<p>Hot stamping steps</p> <ol style="list-style-type: none"><li>1. Ensure that the machine reaches the set time temperature.</li><li>2. Grab the handle of the machine and move it horizontally on the T-shirt.</li><li>3. Press the countdown button.</li><li>4. Use both hands to press the machine and maintain stable pressure.</li><li>5. After the countdown is over, move the machine away.</li></ol> <p>Small post:</p> <p>If the appearance is too light, increase the transfer time.</p> <p>If the color is too dark, reduce the transfer time.</p>
	<p>Hot stamping completed</p> <p>After printing, place the machine on the tray.</p> <p>Be Careful</p> <ol style="list-style-type: none"><li>1. The tray must be stable.</li><li>2. It is prohibited to place flammable materials around the pallet.</li><li>3. The machine will automatically shut down after 30 minutes without human operation.</li></ol>

Manufacturer: Shanghaimuxinmuyeyouxiangongsi

Address: Shuangchenglu 803nong11hao1602A-1609shi, baoshanqu, shanghai 200000 CN.

EC REP: E-CrossStu GmbH.

Mainzer Landstr.69, 60329 Frankfurt am Main.

UK REP: YH CONSULTING LIMITED.

C/O YH Consulting Limited Office 147, Centurion House, London Road, Staines-upon-Thames, Surrey, TW18 4AX

Imported to AUS: SIHAO PTY LTD.

1 ROKEVA STREETEASTWOOD NSW 2122 Australia

Imported to USA: Sanven Technology Ltd.

Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730





Technical Support and E-Warranty Certificate  
[www.vevor.com/support](http://www.vevor.com/support)